

GPS

10,1" Ex-certified Tablet PC
Agile 

Type B7-A234-4.../.....

ATEX / IECEx Zone 2 / 22
UL Class I Division 2


Status: 10th February 2017

Reservation: Technical data subject to change without notice. Changes, errors and misprints may not be used as a basis for any claim for damages.

1.1 Technical Data

GPS	u-blox NEO-6Q module ROM, TCXO
Accuracy	Position 2.5 m
	(prepared for Galileo GPS System)
	More technical data see datasheet of ublox
Interface	COM Port 9 is internal reserved for GPS inside of Agile X

1.2 Application & Drivers


Available from ublox is:	
<ul style="list-style-type: none"> u-blox GNSS u-center 	<p>Tool for use of the GPS module</p> <p>Selection of the Sensor API functionality is shown in the figure below. When u-blox sensor is enabled, the Sensor API should blink green every time sensor location data events are generated.</p>
	
<ul style="list-style-type: none"> u-blox GNSS Standard Driver u-blox GNSS Sensor Driver 	<p>u-blox has created a driver connecting to all u-blox GNSS positioning chips and modules to the Windows Sensor and Location Platform.</p>
	<p>More information can be found in u-blox documentation.</p>

1.3 HotTab Version



The version is shown in the Hottab application in settings menu.

The application can be un-installed over the device centre.

The application can installed as execution file.

<p><u>Information about Tablet PC:</u></p> <ul style="list-style-type: none">• BIOS Version• HotTab Version• OS Version• Serial Number	
---	---

1.4 Activate GPS

<p>Select HotTab  application on desktop.</p>	
<p>The HotTab menu open on the right side of the screen.</p>	
<p>Select Device ON/OFF</p>	

Activate GPS module.

Orange = activated

White = deactivated

Now the GPS feature is ready to be used
with an application utilizing the GPS.

