

User Manual - TRANSLATION**POLARIS PROFESSIONAL**

POLARIS Panel PC Professional 10.4" / 12.1" / 12.1" W
Type 17-71V1-....

ATEX / IECEx / CSA
Zone 1 and Zone 21

Document no. 11-71V1-7D0016 / 366630

Revision 4 / Status: 21 May 2019

Reservation: Technical data subject to change without notice. Changes, errors and misprints may not be used as a basis for any claim for damages.

Content	Pages
English	1 - 63

1.	Basic safety instructions	2
1.1	Notes on this manual	2
1.1.1	Languages	3
1.1.2	Changes in the document	3
1.2	Handling the product	3
1.3	Intended use	3
1.3.1	Exclusive purpose	3
1.3.2	Unintended use	4
1.4	Duties of the operator	4
1.5	Safety information	4
1.5.1	General	4
1.6	General safety information for operation	4
1.6.1	Maintenance	4
1.6.2	Servicing	5
1.6.3	Inspection	5
1.6.4	Repairs	5
1.6.5	Commissioning	5
1.7	Labelling, test certificate and standards	5
1.8	Warranty	5
2.	Product description	7
2.1	Definition	7
2.2	Schematic design	8
3.	Explosion protection and approvals	9
4.	Technical data	11
4.1	POLARIS PROFESSIONAL	11
4.1.1	Characteristics POLARIS Panel PC 10.4"	12
4.1.2	Characteristics POLARIS Panel PC 12.1"	13
4.1.3	Characteristics POLARIS Panel PC 12.1" W	14
4.2	Keyboard	15
4.2.1	Explosion protection	15
4.2.2	General data	15
4.2.3	Characteristics of enclosure for mouse and keyboard	16
4.3	Finger mouse, trackball, touchpad and joystick	16
4.3.1	Explosion protection	16
4.3.2	General data	17
4.3.3	Variants	17
4.4	Ex i Memory stick	18
4.4.1	Explosion protection	18
4.4.2	General data	18
4.5	USB Smart Device	19
4.5.1	Explosionsschutz	19
4.5.2	Technical data	19
4.5.3	Electric data (USB standard)	20
4.5.4	Technical data (Bluetooth)	20
4.5.5	Technical data (WLAN)	20
4.6	Product labelling	21
5.	Transport, storage, scope and assembly	22
5.1	Transport	22
5.2	Intermediate storage	22
5.3	Scope of delivery	22
5.3.1	Accessories optional	22
5.4	Assembly	23
5.4.1	Installation options	23
6.	Installation	24
6.1	Requirements	24
6.2	Mechanical installation	25
6.2.1	Installation in 2G-/2D-enclosure	25
6.2.2	Installation as a system solution in the stainless steel enclosure	27

6.2.3	Floor mounting (Stainless steel enclosure).....	28
6.2.4	Wall mounting (Stainless steel enclosure).....	28
6.3	Electrical Installation	29
6.3.1	Installation guidelines	29
6.4	Terminal compartments	30
6.5	PE conductor connection	31
6.6	Ex e terminal compartments	32
6.6.1	Cable entries	32
6.6.2	Supply voltage terminal assignment).....	33
6.6.3	Ethernet Terminal Assignment	33
6.6.4	RS422 Interface.....	34
6.6.5	RS485 Interface.....	35
6.6.6	PROFIBUS-DP interface (optional)	36
6.6.7	TTY interface (optional)	37
6.6.8	RS232 Interface.....	38
6.6.9	Siemens PROFIBUS-DP interface (optional)	39
6.6.10	USB interface (optional)	40
6.6.11	Interface RS422/USB (optional)	40
6.7	Ex i terminal compartment	41
6.7.1	Connection of Ex i input device to the POLARIS (optional).....	41
6.7.2	Ex i USB interface for BARTEC Ex i memory stick.....	42
6.7.3	Ex d socket (optional)	42
6.7.4	Connection of a BARTEC BCS 160 ^{ex} hand scanner (optional).....	43
6.7.5	Fibre-optic port (optional for 12.1")	44
6.8	EMC (Electromagnetic compatibility)	45
6.8.1	Voltage supply (DC-Variants)	45
6.8.2	Back-up fuse.....	46
6.8.3	Interference suppression	46
6.8.4	Shielding	47
6.8.5	Connection of shielding	47
6.8.6	Examples of Shielding Connections	47
6.8.7	Ethernet cable	48
7.	Commissioning.....	49
7.1	Final Inspection	49
8.	Operation.....	49
8.1	Operating System	49
8.2	Commissioning Software	50
8.2.1	Windows 10 IoT Enterprise LRSB	50
8.2.2	Windows 7 Ultimate	50
8.3	On-board Bartec Recovery Solution	51
8.3.1	Bartec Recovery Solution	51
8.3.2	Start of the device in the Recovery mode.....	51
8.3.3	Recovery surroundings.....	51
8.3.4	Recovery application	53
8.3.5	Restoration in the work state	54
8.3.6	Finish the recovery	56
8.4	Recovery/Backup Function	57
8.4.1	Recovery stick image	57
8.4.2	Backup.....	58
8.4.3	Switching off and shutting down	58
8.5	Network (Ethernet) Setup.....	59
8.6	Keyboard Settings.....	61
8.6.1	Touch Screen	62
9.	Faults and troubleshooting	63
10.	Maintenance, inspection, repair.....	64
10.1	Maintenance intervals	64
10.2	Inspection.....	64
10.3	Maintenance and repair work.....	64
10.3.1	Instructions for Repairs.....	65

11.	Disposal.....	65
12.	Dispatch and packaging instructions.....	65
13.	Accessories, spare parts	66
14.	Order numbers.....	67
15.	Additional information	68
16.	Declaration of conformity	69

1. Basic safety instructions

1.1 Notes on this manual



Read carefully before putting the devices into operation.

The user manual is a fixed part of the product. It must be kept in the direct vicinity of the device and the installation, operating and service staff must have access to it at all times.

The user manual contains important information, safety instructions and test certificates which are necessary for the perfect function of the device in operation.

The user manual is directed at all individuals concerned with the commissioning, handling and servicing of the product. The applicable guidelines and standards for areas with gas and dust atmosphere (2014/34/EU, EN/IEC 60079-17 and EN/IEC 60079-19) must be observed when conducting this work.

Knowledge of the safety and warning information in this user manual and the strict compliance with it is essential for safe installation and commissioning. Accidents, injuries and material damage can be avoided by circumspect handling and systematically following the instructions.

The examples, tables, and figures provided in this user manual are for illustration purposes. Due to the different requirements of the respective application, the BARTEC company cannot assume responsibility or liability for actual use based on the examples and figures.

The BARTEC company reserves the right to carry out technical changes at any time.

In no event will BARTEC company be responsible or liable for indirect or consequential damages resulting from the use or application of this user manual.

Safety instructions and warnings are specially highlighted in these operating instructions and marked by symbols.

DANGER

DANGER describes a directly imminent danger. If not avoided, death or severe injury will be the consequence.

WARNING

WARNING describes a possibly imminent danger. If not avoided, death or severe injury may be the consequence.

CAUTION

CAUTION describes a possibly imminent danger. If not avoided, mild or slight injury may be the consequence.

ATTENTION

ATTENTION describes a possibly damaging situation. If not avoided, the plant or objects in its vicinity may be damaged.



Important information on effective, economical & environmentally compliant handling.

1.1.1 Languages

The original user manual with safety information is written in English. All other available languages are translations of the original user manual.

The user manual is available in German and English. If further languages are required, these must be requested from BARTEC or stated on placing an order.

1.1.2 Changes in the document

BARTEC reserves the right to change the content of this document without notification. No warranty is assumed for the correctness of the information. In cases of doubt, the German safety instructions apply because it is not possible to rule out errors of translation or printing. In the case of legal disputes, the "General Terms and Conditions of Business" of the BARTEC GmbH also apply.

The current versions of the datasheets, operating instructions, certificates and EU declarations of conformity can be downloaded from www.bartec.de or may be requested directly from BARTEC GmbH.

1.2 Handling the product

The product described in these operating instructions has been tested and left the factory in perfect condition as regards meeting safety requirements. To maintain this condition and ensure that this product operates perfectly and safely, it may be used only in the manner described by the manufacturer. Appropriate transportation, suitable storage and careful operation are also essential for the perfect and safe operation of this product. The POLARIS must be installed properly and securely if it is to work perfectly and correctly.

The safe and perfect mounting of the POLARIS is a precondition for faultless and correct operation.

1.3 Intended use

1.3.1 Exclusive purpose

It is used exclusively in combination with operating devices which satisfy the requirements for Overvoltage Category I.

The POLARIS PROFESSIONAL Panel PCs have been designed specially for use in hazardous (potentially explosive) areas in Zone 1 or Zones 21.

It is essential to observe the permissible operational data for the device being used.

1.3.2 Unintended use

Any other use is not in accordance with the intended purpose and can cause damage and accidents. The manufacturer will not be liable for any use beyond that of its exclusive intended purpose.

1.4 Duties of the operator

The owner/managing operator undertakes to restrict permission to work with the POLARIS to people who:

- are familiar with the basic regulations on safety and accident prevention and have been instructed in the use of the POLARIS;
- have read and understood the documentation, the chapter on safety and the warnings.

The owner/managing operator must check that the safety regulations and accident prevention rules valid for the respective application are being observed.

1.5 Safety information

1.5.1 General

- Take the device out of the hazardous area before wiping it with a dry cloth or cleaning it!
- Do not open devices in a hazardous area.
- The general statutory regulations or directives relating to safety at work, accident prevention and environmental protection legislation must be observed, e.g. the German industrial health and safety ordinance (BetrSichV) or the applicable national ordinances.
- In view of the risk of dangerous electrostatic charging, wear appropriate clothing and footwear.
- Avoid the influence of heat that is higher or lower than the specified temperature range.
- Protect the device from external influences! Do not expose the device to any caustic/aggressive liquids, vapours or mist! In the event of malfunctioning or damage to the enclosure, take the device out of the potentially explosive area immediately and bring it to a safe place.

1.6 General safety information for operation

1.6.1 Maintenance

The pertinent erection and operating provisions for electrical systems must be observed! (e.g. Directive RL 2014/34/EU, BetrSichV and nationally applicable ordinances EN 60079-14, IEC 60079-14 and the series DIN VDE 0100)!

Observe the national waste disposal regulations when disposing of materials.

1.6.2 Servicing

No constant servicing will be necessary if operated correctly under consideration of the assembly instructions and environmental conditions. See Chapter "Service, inspection, repair" in this respect.

1.6.3 Inspection

According to EN/IEC 60079-17 and EN/IEC 60079-19, the operator of electrical systems in potentially explosive atmospheres is obliged to have these inspected by an electrician to ensure correct condition.

1.6.4 Repairs

Repairs to explosion-proof equipment may only be performed by persons authorized by BARTEC, who must employ the latest technological practices, observe the manufacturer's instructions and use only original spare parts. The applicable regulations are to be observed here.

1.6.5 Commissioning

It must be checked that all components and documents are available before commissioning.

1.7 Labelling, test certificate and standards

The device features an explosion protection label, as well as a test certificate. For an explanation of the symbols and information used, see chapter 4 "Technical data".

The POLARIS PROFESSIONAL Panel PC series complies with Directive 2014/34/EU on equipment and protective systems intended for use in potentially explosive atmospheres (ATEX Directive). For information on standards that must be observed, see chapter 3 "Explosion protection and approvals".

1.8 Warranty



WARNING

Explosion protection cannot be guaranteed if non-specified components are used.

- ▶ Do not make any changes or perform any reconstruction work on the device.
- ▶ Use only original spare parts.



The manufacturer provides a full warranty exclusively for the spare parts it supplies. When using parts from third parties, there is no guarantee that they have been designed or manufactured to handle the requisite stress or offer the requisite degree of safety.

As a fundamental rule, our "General Conditions of Sale and Delivery" apply. These are made available to the owner/managing operator at the latest on formation of a contract.

Guarantee and liability claims for personal injury and damage to property are excluded if they are due to one or more of the following reasons

- Use of the POLARIS for a purpose other than that for which it is intended.
- Incorrect installation, commissioning, operation and maintenance.
- Non-compliance with the instructions in the manual with respect to transport, storage, assembly, commissioning, operation and maintenance.
- Structural modifications without our prior authorisation.
- Inadequate monitoring of components that are subject to wear
- Repairs done incorrectly.
- Disasters due to the effects of foreign matter or Act of God (events outside human control).

BARTEC grants a warranty period of one year on the POLARIS series, starting from the BARTEC delivery date. The warranty period for accessories is 1 year from the date of delivery. This warranty covers all parts of the delivery and is limited to the free-of-charge replacement of or repair of the defective parts by BARTEC. The packaging supplied should ideally be retained for this purpose (return shipping). If necessary and following written consultation, the products should be sent to us with an RMA form. No claims may be submitted for repair work to be performed at the installation location.

2. Product description

2.1 Definition

The **POLARIS PROFESSIONAL Panel PC** series are the all-rounders for machine-oriented operation and observation in hazardous areas. High-resolution displays with LED technology and touch screen for an intuitive and comfortable operation are now available in the standard variant.

State-of-the-art LED display technology ensures an optimum contrast event with a large viewing angle.




Illustration 1: POLARIS PROFESSIONAL Panel PC series

The POLARIS PROFESSIONAL Panel PC series is open to a great number of software applications. The pre-installed, multi-lingual Windows® 7 Ultimate operating system (optional Windows® 10 IoT LTSC) allows the use of its standard visualisation or the BMS-Graf-pro 7 visualisation software from BARTEC.

This is facilitated by a faster Intel® Atom™ E3845, 4 x 1.91 GHz, which allows an excellent execution of extensive applications locally too. Robust hard disks or solid-state drives are available as storage media also.

A direct connection to the control or to the process control system is possible through Ethernet (copper or FO), PROFIBUS DP or serial COM interfaces. Finger mouse, trackball, touchpad and joystick are available as options.



Of course, here too the user can work with the latest BMS-Graf-Pro Version 7, allowing for example the transmission of projects through Ethernet, the use of graphics lists and integrated user administration.

Wired electrical connections are made via integrated terminal compartments.



The use of the BARTEC Ex i memory stick through the intrinsically safe USB interface allows data to be transferred easily, stored, and saved for system restoration by means of the backup function.

Standard assembly of the POLARIS PROFESSIONAL series is mounting on the front panel which can be performed quickly and easily. On request we also supply the POLARIS PROFESSIONAL series as turn-key system solution in a stainless steel enclosure for wall and floor mounting.



Illustration 2 Types of enclosure

2.2

Schematic design




Illustration 3: Simple set-up with finger mouse







Illustration 4: System configuration with barcode scanner and finger mouse

3. Explosion protection and approvals

POLARIS Panel PC Professionel Type 17-71V1-....																	
ATEX																	
Ex protection type	 II 2G Ex db eb mb q [ib op pr] IIC T4 Gb  II 2D Ex mb tb IIIC T120°C Db -20 °C ≤ Ta ≤ 60 °C																
Certification	IBExU 05 ATEX 1117 X																
Standards in accordance with EMC Directive 2014/34/EU	EN 60079-0:2012+A11:2013 EN 60079-1:2014 EN 60079-5:2015 EN 60079-7:2015 EN 60079-11:2012 EN 60079-18:2015 EN 60079-28:2015 EN 60079-31:2014																
IECEx																	
Ex protection type	Ex db eb qb [ib op pr] IIC T4 Gb Ex tb IIIC T120 °C Db																
Certification	IECEx IBE 11.0007X																
Standards in accordance with EMC Directive 2014/34/EU	<table border="0"> <tr> <td>IEC 60079-0:2011</td><td>Edition: 6</td></tr> <tr> <td>IEC 60079-1:2014-06</td><td>Edition: 6</td></tr> <tr> <td>IEC 60079-5:2015</td><td>Edition: 4</td></tr> <tr> <td>IEC 60079-7:2015</td><td>Edition: 5</td></tr> <tr> <td>IEC 60079-11:2011</td><td>Edition: 6</td></tr> <tr> <td>IEC 60079-18:2015</td><td>Edition: 4</td></tr> <tr> <td>IEC 60079-28:2015</td><td>Edition: 2</td></tr> <tr> <td>IEC 60079-31:2013</td><td>Edition: 2</td></tr> </table>	IEC 60079-0:2011	Edition: 6	IEC 60079-1:2014-06	Edition: 6	IEC 60079-5:2015	Edition: 4	IEC 60079-7:2015	Edition: 5	IEC 60079-11:2011	Edition: 6	IEC 60079-18:2015	Edition: 4	IEC 60079-28:2015	Edition: 2	IEC 60079-31:2013	Edition: 2
IEC 60079-0:2011	Edition: 6																
IEC 60079-1:2014-06	Edition: 6																
IEC 60079-5:2015	Edition: 4																
IEC 60079-7:2015	Edition: 5																
IEC 60079-11:2011	Edition: 6																
IEC 60079-18:2015	Edition: 4																
IEC 60079-28:2015	Edition: 2																
IEC 60079-31:2013	Edition: 2																
 Special conditions	<p>The intrinsically safe circuits and the enclosure are galvanically connected. The equipotential bonding must be guaranteed at the installation of the intrinsically safe circuits.</p> <p>High charging mechanisms at the operation surface of the Visual units respectively accessories (for example pneumatic particle transport) must be excluded at the application. The degree of protection (IP code) must be ensured by the installation of the units in enclosures (IP code).</p>																



Die POLARIS HMI are marked exclusively according to ATEX und IECEx.
 Future markings must be requested separately.


Further test certificates	
INMETRO	11/UL-BRHZ-0131X
Customs Union Russia (EAC)	TC RU C-DE.GB06.B.00334
Korea	KTL 14-KB4BO-0258X
India	CCEs P261984
China	NEPSI GYJ18.1382X
American	CSA 70010166
More test certificates	www.bartec.de
EU-conformity	
RoHS-Directive	2011/65/EU
Standards in accordance with EMC Directive 2014/30/EU	EN/IEC 61000-6-2:2005 EN 61000-6-4:2007 + A1:2011 IEC 61000-6-4:2006 + A1:2010 EN 60529:1991 + A1 2000 + A2 :2013 IEC 60529:1989 + A1 1999 + A2 :2013
Electrical safety	EN/IEC 61010-1:2010
Product labelling	CE 0044

4. Technical data

4.1 POLARIS PROFESSIONAL


Construction	Front panel fitting, optional turn-key system solutions in a stainless steel enclosure as floor or wall mounting.
Computer capacity	Intel® Atom™ E3845, 4 x 1.91 GHz Graphics memory 4 or 8 GB RAM 100 GB HD or 128 GB SSD (MLC)
Operating system	Windows® 7 Ultimate Windows® 10 IoT LTSC Open platform for customer-specific visualization software, e. g. ProTool, WIN CC flexible, etc.
Display	Antireflection coating glass pane Optional touchscreen
Power supply	DC 24 V ±10 %
Relative air humidity	5 to 95 % non-condensing
Vibration	0.7 G/1 mm; 5 Hz-500 Hz pulse in all 3 axes
Shock	15 G, 11 ms pulse in all 3 axes
Permissible ambient temperature Storage Operation Variant	-20 °C to +50 °C 0 °C to +50 °C Operation: -20 °C to +50 °C on request (System solution with heating)
Material Front Rear panel	Polyester foil on anodised aluminium plate (conditionally UV-resistant) galvanised sheet steel, bichromated
Protection class Front Rear site	IP66 IP54
Optional approved accessories	Keyboard Mouse variants Ex i USB memory stick Smart USB Device

4.1.1 Characteristics POLARIS Panel PC 10.4"




Display	10.4" graphics-capable TFT colour display SVGA resolution 800 x 600 pixels 262,144 colours Brightness 400 cd/m ² Visible surface approx. 211 x 158 mm Contrast 700:1
Keyboard (short-stroke keys)	Alphanumeric key block 4 cursor keys 10 special keys 12 function keys able to be labelled with LEDs
Interface (basic version)	1 x Ex e Ethernet 100/10BaseT 1 x Ex e RS422 1 x Ex i USB for Ex i memory stick 1 x Ex i for PS/2 for intrinsically safe mouse
Optional interface modules	1 x Ex i Supply module for hand-held scanner
Max. power consumption	P _{max} < 30 W
Dimensions (width x height x depth)	400 mm x 246 mm x 130 mm
Wall cut-out (width x height)	386 mm x 226 mm ± 0.5 mm
Weight	approx. 14 kg

4.1.2 Characteristics POLARIS Panel PC 12.1"



Display	12.1" graphics-capable TFT colour display XGA resolution 1024 x 768 pixels 15.6 mio. colours Brightness 500 cd/m ² Visible surface approx. 246 x 184 mm Contrast 700:1
Front keys	Alphanumeric key block 4 cursor keys 12 special keys 16 function keys able to be labelled with LEDs
Interface (basic version)	1 x Ex e Ethernet 100/10BaseT 1 x Ex e RS422 1 x Ex i USB for Ex i memory stick 1 x Ex i for PS/2 for intrinsically safe mouse
Optional interface modules	1 x Ex i Supply module for hand-held scanner 1 x Fibre-optic
Max. power consumption	P _{max} < 35 W
Dimensions (width x height x depth)	440 mm x 275 mm x 130 mm
Wall cut-out (width x height)	425 mm x 255 mm ± 0.5 mm
Weight	approx. 18 kg

4.1.3 Characteristics POLARIS Panel PC 12.1" W



Display	12,1" graphics-capable TFT colour display WXGA resolution 1280 x 800 pixels 15.6 mio. colours Brightness 500 cd/m ² Visible surface approx. 261 x 163 mm Contrast 1000:1
Interface (basic version)	1 x Ex e Ethernet 100/10BaseT 1 x Ex e RS422 1 x Ex i USB for Ex i memory stick
Optional interface modules	1 x Ex i Supply module for hand-held scanner 1 x Ex d USB direct connection (via Ex d socket)
Max. power consumption	P _{max} <35 W
Dimensions (width x height x depth)	400 mm x 246 mm x 130 mm
Wall cut-out (width x height)	386 mm x 226 mm ± 0.5 mm
Weight	approx. 14 kg

Variant with front keys

Front keys	10 special keys 12 function keys able to be labelled with LEDs
Interface (basic version)	1 x Ex i for PS/2 for intrinsically safe mouse

Variant without front keys

Front keys	none
Interface (basic version)	2 x Ex i for PS/2 for intrinsically safe mouse and keyboard

4.2.3 Characteristics of enclosure for mouse and keyboard




Order no.	05-0041-0277
Material	Stainless steel 1.4301; AISI 304
Dimensions (width x height x depth)	600 mm x 85 mm x 220 mm
Protection class	IP65
Dimensions (mm) 	

4.3 Finger mouse, trackball, touchpad and joystick


4.3.1 Explosion protection

Ex protection type ATEX	II 2G Ex ib IIC T4 Gb II 2D Ex ib IIIC T120°C Db -20 °C ≤ Ta ≤ +60 °C (50°C)
Certification	IBExU 05 ATEX 1117 X
Ex protection type IECEx	Ex ib IIC T4 Gb Ex ib IIIC T120 °C Db
Certification	IECEX IBE 11.0007X
More test certificates	www.bartec.de

4.3.2 General data

Construction	Front panel fitting
Material	Polyester foil on aluminium sheet (conditionally UV-resistant)
Protection class	
Fingermouse/Joystick/Touchpad	IP65 front site
Trackball	Static IP65 front site
	Dynamic IP56 front site
Dimensions (width x height)	130 mm x 170 mm
Wall cut out (width x height)	100 mm x 140 mm
<p>Dimensions and wall cut-out (mm)</p>  <p>* nur/only Joystick</p>	

4.3.3 Variants



Finger mouse	Type 17-71VZ-1000
Installation depth	15 mm
Weight	approx. 270 g
Touchpad	Type 17-71VZ-2000
Installation depth	15 mm
Gewicht	approx. 250 g
Trackball	Type 17-71VZ-3000
Installation depth	43 mm
Weight	approx. 500 g
Joystick with button	Type 17-71VZ-9000
Installation depth	43 mm
Weight	approx. 500 g

4.4

Ex i Memory stick

4.4.1

Explosion protection



Type	17-71VZ-5000/0100
Ex protection type ATEX	II 2 G Ex ib IIC T4 Gb -20 °C ≤ Ta ≤ 60 °C (50°C)
Certification	IBExU 05 ATEX 1117 X
Standards	EN 60079-0:2009 EN 60079-11:2012 EN 60079-31:2009
Ex protection type IECEx	Ex ib IIC T4
Certification	IECEx IBE 11.0007X
Standards	IEC 60079-0:2007 Edition: 5 IEC 60079-11:2011-06 Edition: 6 IEC 60079-31:2008 Edition: 1
More test certificates	www.bartec.de

4.4.2

General data

Product type	USB flash drive
Storage capacity	4 GB
Dimensions (length x width x depth)	approx. 92 mm x 22 mm x 7.2 mm
Weight	28 g
Enclosure material	Anodised aluminium
Use	Data backup

4.5 USB Smart Device

4.5.1 Explosionsschutz

Type	17-71VZ-A0x0/0000
Ex protection type ATEX	<div> <div>II 2G Ex eb mb IIC T4 Gb</div> <div>II 2D Ex tb IIIC T120 °C Db</div> </div>
Certification	IBExU 05 ATEX 1117 X
Kennzeichnung IECEX	<div>Ex eb mb IIC T4</div> <div>Ex tb IIIC T120 °C</div>
Certification	IECEX IBE 11.0007X
Possible ambient temperature	-20 °C bis + 60 °C
Protection class	IP 66 (threaded base)



Suitable for the installation in 2G-, 2D-, 3G- or 3D enclosure. Connection via USB Ex-e.

4.5.2 Technical data

Fastening	M30 x 1,5 (suitable for fixing holes 30,3mm with recess for anti-twist safeguard)
Installation	Wall thickness 1mm to 6mm impact resistance: 7Nm
Torque of panel nut	2,8 to 3,4 Nm
Material	Enclosure thermoplastic

Dimensions

	mm	in
A	70	2.8
B	16,5	0.65
C	Ø 30,3 ^{+0,3}	Ø 1.9 ^{+0,01}
D	3	0.12
E	40	1.6

Fixing hole of the size Ø 30,3 mm (1.9 in) with recess for anti-twist safeguard, typical position on top (12 o'clock position).

Minimum distances of the fixing holes:

- horizontal 40 mm (1.6in)
- vertical 70 mm (2.8 in)

Recommended distance for mushroom push button, shock switch as well as selector switch with protective collar: 100 mm (3.9 in)

4.5.3 Electric data (USB standard)

USB-connection	Colour	Function
1	RD	V+
2	WH	Data- USB-data signal
3	GN	Data+ USB-data signal
4	BK	V-

Bluetooth



4.5.4 Technical data (Bluetooth)

Bluetooth	M30 x 1,5 (suitable for fixing holes 30,3mm)
Downward compatible	Wandstärke 1mm bis 6mm Schlagfestigkeit: 7Nm
Range	2,8 bis 3,4 Nm
For more technical data see description of the bluetooth-stick manufacturer.	

WLAN


For the wireless network connection.




4.5.5 Technical data (WLAN)

Wifi - standard	IEEE802.11n IEEE802.11g IEEE802.11b
Transfer rate	max. 150 Mbit/s
WLAN - frequency	2.4 GHz
For more technical data see description of the W-LAN-stick manufacturer.	

4.6 Product labelling




A
Example:
Type label with label
ATEX and IECEx



B
IMMETRO
type label



C
Warnings on the
device



D
Warning on terminal
compartment!



E
License sticker

depending on the operating system

F
Test sticker



5. Transport, storage, scope and assembly

5.1 Transport



A written report of any transport damage or missing items must be given to the appointed forwarder and to BARTEC GmbH immediately on receipt of the delivery.

Damage caused by incorrect storage and transport shall not fall within the warranty provisions of BARTEC GmbH.

CAUTION

This device is heavy (10-18 kg).

There is a risk of injury if it is lifted or moved incorrectly.

► You will need help from others when transporting it.

5.2 Intermediate storage

ATTENTION

Damage to property through incorrect storage!

- Comply with the correct storage temperatures.
- Keep the POLARIS free of moisture.

5.3 Scope of delivery

- 1 x POLARIS PROFESSIONAL Panel PC
- 1 x Reinforcement frame
- 1 x Set of mounting clamps
- 1 x User manual POLARIS PROFESSIONAL – Panel PC

Not enclosed

- Assembly material
- Cable for voltage supply and data line

5.3.1 Accessories optional

- Enclosure and supporting system for wall, floor and table mounting
- Keyboard (only at device with front keys), finger mouse, touchpad, trackball, joystick
- Fibre optic converter

5.4 Assembly

Before assembling the device, make sure you have all the components and documents.

Required Tools:	POLARIS (mounting clamps)	1 x hex key 3 mm 1 x slotted screwdriver
	POLARIS termination-compartments	1 x hex key 2,5 mm 1 x slotted screwdriver
	POLARIS PE-connection	1 x ring spanner 7 mm

5.4.1 Installation options

The POLARIS can be installed directly in:

- Enclosures
- Switch cabinet doors
- Operating consoles

The POLARIS series are mounted by fitting them into front panels, which can be done with very little effort. On request, we supply the operating devices as ready-to-use system solutions in stainless steel enclosures for mounting onto walls, and floors.




Illustration 5: Examples of floor, wall and table mounting in an "Exclusive II" enclosure

6. Installation



We recommend setting up and testing the entire system before its ultimate installation in the ex-area. If a long connection cable is not available, please use a patch cable to test the basic functions.

DANGER

Electrostatic charging through a stream of particles.

There is a risk of fatal injury in an explosive atmosphere!

- ▶ Make sure there are no highly energetic charging mechanisms at the user interface on the display unit or its accessories.
- ▶ Do not install the device in the stream of particles.

DANGER

No PE connection. Risk of fatal injury in an explosive atmosphere!

- ▶ The POLARIS must be integrated in the equipotential bonding.



The POLARIS Series is approved for an ambient temperature of from 0 °C to +50 °C or from -20 °C to +50 °C and a relative air humidity of from 5 to 95 % without condensation.

6.1 Requirements

- The place where the POLARIS is installed must have sufficient mechanical stability/fastening.
- The enclosure intended for accommodating the POLARIS must be designed to bear the device's weight.
- If a supporting system is used, the surface underneath and the means of fastening the supporting system must be designed to bear the weight of the POLARIS

Selecting the location

CAUTION

Pay attention to wall and ground condition!

A sufficiently stable wall (e.g. concrete or limestone) or floor (e.g. concrete) must be selected for securing the load-bearing system.

- ▶ The structural stability of the wall or floor must be able to bear 4 times the weight of the POLARIS as system solution.
- ▶ The support arm system must be assembled using suitable mounting materials (M12) (e.g. dowels or stud bolts).

- Choose the optimum height for operating the POLARIS.
- Ensure good lighting conditions for a perfectly legible display (no direct exposure to the sun's rays).

- Do not mount in direct proximity to switching or current changing devices.
- Only install the POLARIS in conjunction with the reinforcement frame in an IP65 enclosure. Failure to comply with this can lead to water penetrating and damaging the device.

Outdoor installation

ATTENTION

Damage from condensation or overheating!

- ▶ Avoid direct sunlight!
Remedy: e.g. shelter with sufficient air circulation.
- ▶ Remove condensation on the POLARIS immediately.
- ▶ A POLARIS built into an enclosure must be heated and not removed from the mains.
- ▶ Equip the protective housing with breather.

6.2 Mechanical installation

CAUTION

This device is heavy (10-18 kg).

There is a risk of injury if it is lifted or moved incorrectly.

- ▶ You will need help from others when transporting it.



Only qualified personnel, i.e. trained skilled specialists will have the necessary specialised know-how to be able to perform all the mechanical work. Familiarity with and the technically perfect implementation of the safety instructions described in this manual are preconditions for safe installation and commissioning.

6.2.1 Installation in 2G-/2D-enclosure

In order to guarantee the IP degree of enclosure protection = IP54 for installation in 2G enclosures of Ex e type of protection (e.g. control equipment), and = IP6X for installation in 2D enclosures in areas where combustible dusts exist - with "protection through the enclosure" type of protection - the reinforcement frame should be used for fastening on the front side.

A reinforcement frame is inserted between the retaining brackets and the enclosure material for good transmission of the clamping force. This ensures even transmission of force.



For POLARIS built into the enclosure door

The open door must be supported and secured during the installation and servicing phase. Otherwise the wall thickness specified may lead to the door sagging slightly when open.

⚠ DANGER

If there is no reinforcement frame, it will not be possible to maintain the IP protection. There is a risk of fatal injury in an explosive atmosphere!

- ▶ Only use enclosure with at least 2 mm wall thickness.
- ▶ Insert the reinforcement frame between the holder and the enclosure.

Reinforcement frame for maintenance of Protection Class IP65

POLARIS 10.4" / 12.1" W	05-0205-0008
POLARIS 12.1"	05-0205-0007



Fit the reinforcement frame

Illustration 6: Minimum installation depth and mounting reinforcement frame

Work steps

- (1) Insert the POLARIS into the cut-out in the enclosure.
- (2) From the back, place the reinforcement frame over the POLARIS.
- (3) Using the M4x12 (2) screws to fasten the mounting clamps (1) to the rear side of the POLARIS and tighten to 1.37 Nm.
- (4) Tighten the clamping screw (3) of the mounting clamps to a torque of 1.02 Nm.

**Numbers of mounting clamps**

POLARIS Professional
10.4" / 12.1" / 12.1" W

6 pieces



Always tighten the mounting clamps crosswise.

6.2.2 Installation as a system solution in the stainless steel enclosure

The POLARIS is available as a ready-made system solution in a stainless steel enclosure e.g. for floor, wall or table mounting.



CSA approval

The CSA approval for the POLARIS series only includes the basic device POLARIS PROFESSIONAL.

Other system solutions and mounting systems (e.g. table mounting) have **not** been tested and approved in accordance with CSA.



For POLARIS built into the enclosure door

The open door must be supported and secured during the installation and servicing phase. Otherwise the wall thickness specified may lead to the door sagging slightly when open.

Selecting the location



CAUTION

Pay attention to wall and ground condition!

- ▶ A sufficiently stable wall (e.g. concrete or limestone) or floor (e.g. concrete) must be selected for securing the load-bearing system.
- ▶ The structural stability of the wall or floor must be able to bear 4 times the weight of the POLARIS as system solution.
- ▶ The support arm system must be assembled using suitable mounting materials (M12) (e.g. dowels or stud bolts).

Stainless steel enclosure "Basic" for floor and wall mounting

Type	Dimensions (Width x Height x Depth)
POLARIS 10.4" / 12.1" W	560 mm x 320 mm x 200 mm
POLARIS 12.1"	600 mm x 350 mm x 200 mm

Work steps

- (1) Prepare supply and data line(s).
- (2) Prepare installation on the basis of the drilling template (see illustration 7 - 8).
- (3) Install supply and data line(s) in the base.
- (4) Fasten the supporting system.
- (5) Pull supply and data line(s) through the cable glands provided into the enclosure. Ensure there is sufficient length.
- (6) Mount the enclosure on the supporting system.
- (7) Open the terminal compartments on the POLARIS and feed the supply and data line(s) through the cable glands and wire them. Block unused terminal compartments with a blanking plug.
- (8) Close the door of the enclosure.

6.2.3 Floor mounting (Stainless steel enclosure)




Illustration 7: Drilling pattern - supporting system for floor mounting

6.2.4 Wall mounting (Stainless steel enclosure)




Illustration 8: Drilling pattern - supporting system for wall mounting

6.3 **Electrical Installation**

6.3.1 **Installation guidelines**



Only qualified personnel, i.e. trained electricians will have the required specialised knowledge to be able to do all the electrical work.

Familiarity with and the technically perfect implementation of the safety instructions described in this manual are preconditions for safe installation and commissioning.

- The user may do only the wiring at the terminals that are accessible to him/her (Ex i and Ex e terminal compartment).
- Any unused cable glands on the Ex e terminal compartment should be closed using an approved blanking plug.
- More extensive dismantling work on the device may be done only by the manufacturer or by persons authorised by the manufacturer for this purpose. The device is factory-sealed. Never open it!
- The equipotential bonding connection point must be connected to the equipotential bonding conductor in the hazardous area. Since the intrinsically safe circuits are galvanically connected to earth, equipotential bonding is required throughout the entire installation of the intrinsically safe circuits.
- The safety and accident prevention regulations applicable to the respective individual case must be observed.
- Devices must be properly installed first before they may be operated.
- It must be possible at all times to disconnect the devices from the voltage supply (in fixed installations by means of an all-pole mains isolating switch or fuse).
- It must be ensured that the supply voltage agrees with the specifications in this user manual and the tolerances must be observed. Use smoothed direct current.
- Malfunctioning cannot be ruled out if levels exceed or drop below the specified tolerances.
- If there is a power failure or if the power supply is interrupted, make sure the system has not been put into a dangerous, undefined condition.
- EMERGENCY STOP mechanisms must remain effective throughout all modes and states of operation.
- Connection cables (particularly data transmission cables) must be selected and laid in a way that ensures that capacitive and inductive interference will not have any adverse effect on the equipment. Appropriate measures must be taken to handle line interruptions to prevent any undefined states occurring.
- Wherever malfunctioning can cause material damage or personal injuries, additional external safety circuits must be provided (e.g. limit switch, mechanical interlocking devices etc.).

6.4 Terminal compartments

DANGER

Sealed locking screw! The device is closed in the factory.

The explosion protection is lost if opened, and danger to life exists in an explosive atmosphere!

- ▶ Do not open the locking screw!

DANGER

Non-certified cable glands and non-sealed cable entries endanger the IP protection and accordingly the protection against explosions.

There is a risk of fatal injury in an explosive atmosphere!

- ▶ Use Ex-certified cable glands.
- ▶ Close non-sealed cable entries.




Illustration 9: Pin assignment POLARIS



All connection screws and terminals in the terminal compartment must be tightened with a torque spanner under consideration of the recommended torque of 0.4 Nm up to a max. 0.5 Nm.

6.5 PE conductor connection

⚠ DANGER

Death or danger of injury as a result of no PE conductor connection.

There is no explosion protection.

- Equipotential bonding with a core cross-section of at least 4 mm² is to be set up for the POLARIS (see Figure).

Stainless steel enclosure

- Attach equipotential bonding to the enclosure.
- All moving parts must be earthed.
- Secure PE conductor connections against self-loosening.




Illustration 2: PE conductor connection POLARIS

Work steps:

- (1) Washer on to earthing stud
- (2) Push non-sheathed cable with PE cable lug (1) on to earthing stud.
- (3) Washer then position spring washer (2) on threaded bolt and secure with hexagonal nut (3), max. Torque: 2.9 Nm.
- (4) Lay cable close to enclosure so that it cannot become loose.

ATTENTION

Device can be damaged by differences in potential!

- Avoid differences in potential (see Chapter 6.8.5)

6.6 Ex e terminal compartments

6.6.1 Cable entries

When connecting cables and leads to supplies / communications equipment in increased safety protected areas, Ex certified cable entries must be used which are suitable for each type of cable and lead. You must maintain the protection concept "e" and include a suitable sealing element so that an IP rating of at least IP 54 is maintained.



The terminal area of the M20 cable glands is printed on the cable glands.

A different terminal area may only be substituted with a cable gland that complies with the current version of the approval.

The assembly instructions and installation conditions for the cable glands must be observed.

Tightening torque of the cable glands

Torque	Connecting thread	Nut
non-armoured cables	2.3 Nm	1.5 Nm
armoured cables	8 Nm	5 Nm

DANGER

Do not connect cables and leads when the power supply is active.

Danger to life exists in an explosive atmosphere!

- ▶ Disconnect the device before starting work.
- ▶ Only use certified cable glands that have been approved for the cable diameter of the connection cable.
- ▶ Unused cable glands must be sealed using an approved blanking plug.

6.6.2 Supply voltage terminal assignment)


Mains Connection Variant DC 24 V			
Terminal	Interface	Signal	Remarks
X10	Supply	+	DC 24 V \pm 10 %
X11	Supply	-	0 Volt
X12	Supply	PE	Protective earth

6.6.3 Ethernet Terminal Assignment

Configuration Ethernet 10BaseT			
Terminal	Interface	Signal	Remarks
X13	Ethernet	RxD +	100/10 BaseT Receive positive
X14	Ethernet	RxD -	100/10 BaseT Receive negative
X15	Ethernet	TxD +	100/10 BaseT Transmit positive
X16	Ethernet	TxD -	100/10 BaseT Transmit negative

Assignment RJ45 plug for Ethernet to POLARIS terminal block


Connection RJ45		POLARIS
PIN	Signal	Terminal
1	TX+	X13
2	TX-	X14
3	RX+	X15
4	not used	
5	not used	
6	RX-	X16
7	not used	
8	not used	



6.6.4 RS422 Interface

Configuration RS422				
Terminal	Interface	Signal	Remarks	
X17 X18	Termination On/Off		Jumper between terminal X17 and X18 for activation of the terminator resistors	
X19	Interface COM 1	TxD B (TxD+)	Transmission cable	Input
X20	Interface COM 1	TxD A (TxD-)	Transmission cable	Input
X21	Interface COM 1	RxD B (RxD+)	Receiving cable	Input
X22	Interface COM 1	RxD A (RxD-)	Receiving cable	Input

Connection PLC with RS422 interface to POLARIS.



Maximum length of the data line 1,000 m.



Pins 19-23, 20-24, 21-25, 22-26 are already connected inside.


Setting of the terminal resistors at the start and end of the bus line is not necessary in most cases due to internal EMC measures. Depending on local circumstances, the data transmission may worsen in individual cases.

The appropriate pin assignment of the controller can be found in the manufacturer's interface description.

6.6.5 RS485 Interface

Configuration RS485			
Klemme	Schnittstelle	Signal	Bemerkungen
X17	N.C.		
X18	N.C.		
X19	Interface COM 1	TxD B (TxD+)	to PLC
X20	Interface COM 1	TxD A (TxD-)	
X21	N.C.		
X22	N.C.		
X23	N.C.		
X24	N.C.		
X25	Interface COM 1	RxD B (RxD+)	to next POLARIS
X26	Interface COM 1	RxD A (RxD-)	

Connection PLC with RS485 to POLARIS



Maximum length of the data line 1,000 m



The appropriate pin assignment of the controller can be found in the manufacturer's interface description.

6.6.6 PROFIBUS-DP interface (optional)




The PROFIBUS DP (BARTEC) interface can be used only in conjunction with the BMS-Graf-pro 7 visualisation software

Configuration PROFIBUS-DP (BARTEC)

Terminal	Interface	Signal	Remarks
X17	not connected		
X18	not connected		
X19	Interface COM 1	Termination B2	Bridge for terminating network (B1-B2)
X20	Interface COM 1	Termination A2	Bridge for terminating network (A1-A2)
X21	Interface COM 1	Termination B1	Bridge for terminating network (B1-B2)
X22	Interface COM 1	Termination A1	Bridge for terminating network (A1-A2)
X23	Interface COM 1	Out B	Signal B Output
X24	Interface COM 1	Out A	Signal A Output
X25	Interface COM 1	In B	Signal B Input
X26	Interface COM 1	In A	Signal A Input

Connection of a controller via the PROFIBUS-DP interface of the POLARIS.



Maximum line length: see PNO specification.




Pins 26-24-22, 25-23-21 are already connected inside.

See the interface description from the controller manufacturer for the relevant pin assignment of the controller.


6.6.7 TTY interface (optional)

Configuration TTY			
Terminal	Interface	Signal	Remarks
X17	Not connected		
X18	Not connected		
X19	Interface COM 1	GND	Signal ground for receiver
X20	Interface COM 1	Rx-	Cathode
X21	Interface COM 1	Rx+	Anode
X22	Interface COM 1	20 mA	Signal power source for receiver
X23	Interface COM 1	GND	Signal ground for transmitter
X24	Interface COM 1	Tx-	Emitter
X25	Interface COM 1	Tx+	Collector
X26	Interface COM 1	20 mA	Signal power source for transmitter

The transmitter is active and the receiver is passive in both the POLARIS and the control.



In the POLARIS the transmitter and receiver are active. The control is completely passive.



Maximum line length depending on baud rate of up to 1,000 m.




See the interface description from the controller manufacturer for the relevant pin assignment of the controller.

6.6.8 RS232 Interface

Configuration RS232			
Terminal	Interface	Signal	Remarks
X17	Not connected		
X18	Not connected		
X19	Not connected		
X20	Not connected		
X21	Not connected		
X22	Not connected		
X23	Not connected		
X24	Interface COM 1	RxD	Receive
X25	Interface COM 1	TxD	Transmit
X26	Interface COM 1	GND	Signal ground

Connection of a controller via RS232 interface of the POLARIS.



Maximum length of the data line 15 m.



See the interface description from the controller manufacturer for the relevant pin assignment of the controller.

6.6.9 Siemens PROFIBUS-DP interface (optional)




Possible only with the POLARIS Panel PC 12.1"!

Configuration Siemens PROFIBUS (supported only WinCC flexible)

Terminal	Interface	Signal	Remarks
X17	Not connected		
X18	Not connected		
X19	Interface COM 1	B*	Termination
X20	Interface COM 1	A*	Termination
X21	Interface COM 1	LTG-B	Out B
X22	Interface COM 1	LTG-A	Out A
X23	Interface COM 1	LTG-B	In B
X24	Interface COM 1	LTG-A	In A
X25	Interface COM 1	RTS-AS	
X26	Interface COM 1	M5V	

Connection of a controller via a Siemens PROFIBUS-DP interface of the POLARIS.



Maximum line length: see PNO specification.




Pins 24-22, 23-21 are already connected inside.

See the interface description from the controller manufacturer for the relevant pin assignment of the controller.

6.6.10 USB interface (optional)

Configuration USB		
Terminal	Interface	Signal
X17 - X22	not connected	
X23	USB	VCC +5 V
X24	USB	Data- USB data signal
X25	USB	Data+ USB data signal
X26	USB	GND

The individual conductors are colour-coded in a 4-wire USB cable as follows:

	Plug Type A	Socket Type A								
	<table><tr><td>4</td><td>3</td><td>2</td><td>1</td></tr></table>	4	3	2	1	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td></tr></table>	1	2	3	4
	4	3	2	1						
	1	2	3	4						
Plug Type B	Socket Type B									
<table><tr><td>1</td><td>2</td></tr><tr><td>4</td><td>3</td></tr></table>	1	2	4	3	<table><tr><td>2</td><td>1</td></tr><tr><td>3</td><td>4</td></tr></table>	2	1	3	4	
1	2									
4	3									
2	1									
3	4									

Panel PC	USB connection	Colour	Function
X23	1	RD	VCC (+5 V)
X26	4	BK	GND
X25	3	GN	+ Data
X24	2	WH	- Data



The maximum length of a lead should not exceed 2 m.

Maximum current: 300 mA.

When configuration the HMI (Outside the Ex area) it is recommended to use an external USB HUB (USB 2.0) to work.

6.6.11 Interface RS422/USB (optional)

Configuration RS422/USB				
Terminal	Interface	Signal		
X17 - X18	not connected			
X19	COM 1	TxD B (TxD+)	Transmission cable	Input
X20	COM 1	TxD A (TxD-)	Transmission cable	Input
X21	COM 1	RxD B (RxD+)	Receiving cable	Input
X22	COM 1	RxD A (RxD-)	Receiving cable	Input
X23	USB	VCC	+5 V	
X24	USB	Data-	USB data signal	
X25	USB	Data+	USB data signal	
X26	USB	GND		

6.7 Ex i terminal compartment

DANGER

Accessories which have not been approved jeopardise the explosion protection.
Danger to life exists in an explosive atmosphere!
 ► Only use POLARIS accessories!



The cover for the Ex i terminal compartment need not be used when deploying a protective enclosure with protection class of at least IP20.

6.7.1 Connection of Ex i input device to the POLARIS (optional)



Do not connect the keyboard, mouse, trackball, touchpad, joystick while the power supply is active.

POLARIS with front keys

PS/2 for input devices (mouse)				
Terminal	Interface	Colour	Signal	Remarks
X4	PS/2	WH/BR	VCC	Supply voltage
X5	PS/2	GN/YE	GND	Mass connected to protective earth
X6	not used			
X7	not used			
X8	PS/2	BL	MS_CLK	Mouse clock signal
X9	PS/2	RD	MS_DATA	Mouse data signal

POLARIS without front keys

PS/2 for input devices (mouse and keyboard)				
Terminal	Interface	Colour	Signal	Remarks
X4	PS/2	WH/BR	VCC	Supply voltage
X5	PS/2	GN/YE	GND	Mass connected to protective earth
X6	PS/2	PK	KB_CLK	Keyboard clock signal
X7	PS/2	GR	KB_DATA	Keyboard data signal
X8	PS/2	BL	MS_CLK	Mouse clock signal
X9	PS/2	RD	MS_DATA	Mouse data signal

- Make the connection between the POLARIS and the Ex i keyboard.
- Connection by means of a 1.80-metre-long connection cable
- Keyboard and mouse Type 05-0068-0163
- Keyboard and trackball/joystick Type 05-0068-0172
- Keyboard and touchpad Type 05-0068-0183
- (Optional: 3-metre-long connection cable)

6.7.2 Ex i USB interface for BARTEC Ex i memory stick

USB socket, 4-pole, Type A

ATTENTION

The Ex i interface has not been designed for USB devices with their own power supply. **Damage to property through incorrect use!**

- ▶ Do not connect any USB equipment with its own power supply to the Ex i interface.

Extension of the USB when using a protective enclosure (IP20)



The USB wall bushings on the protective enclosure must correspond at least to protection class IP20.

The following types of cable should be used for the extension (max. 2 m).

Cable name: Inline E258105 AWM STYLE 2725, 80°C 30V VW-1
 28AWGX1P, 24AWGX2C; USB 2.0 High speed cable

6.7.3 Ex d socket (optional)




DANGER

Live plug-in connections! Risk of fatal injury if opened in an explosive atmosphere!

- ▶ Before opening the protective cap on the Ex socket on the POLARIS, make sure there is no connection to voltage.
- ▶ Plug-in connections must be closed with a protective cap immediately after separation. The closing element must be positioned correctly.
- ▶ Use flanged socket outlets and appliance couplers only with appropriate plug-in connectors/couplings that are not damaged in any way.



Plug-in connectors in the (red insert) series cannot be combined with plugs in the new geometrically modified (green insert) series. When replacements are delivered, the plug-in system must be replaced in pairs.



PIN	Signal	Colour
Pin 1	VCC1	RD
Pin 2	Data-	WH
Pin 3	Data +	GN
Pin 4	GND	BK

6.7.4 Connection of a BARTEC BCS 160^{ex} hand scanner (optional)



Do not connect the hand scanner when there is an active power supply.

Configuration of hand scanner connection (optional)

Terminal	Interface	Signal	Remarks
X1	Hand-held scanner	+UB	Supply voltage +5 V
X2	Hand-held scanner	RxD-I	Data input RS232-Signal
X3	Hand-held scanner	GND	Earth connected to protective ground
Intrinsically safe data and supply current circuits Terminals X1-X3		U ₀	5.5 V
		I ₀	440 mA
		P ₀	1.25 W
		R _i	25 Ω
		C ₀	55.8 μF
		L ₀	0.2 mH



The BCS 160^{ex} hand scanner series can only be used with the original connection cable from BARTEC. Not compatible is the hand scanner BCS 160^{ex} with 1D-/2D-Imager (Type 17-21BA-M31S/I0000000)

Connection cable to BCS 160^{ex} Barcode hand scanner (pre-assembled)


Cable specified for connection to:	Scanner cable	Version	Length	BARTEC order no.
POLARIS supply module	RS232/RS422	smooth	1.8 m	17-21BE-M000/0000
	RS232/RS422	spiral	3.8 m	17-21BE-M010/0000

Connection cable to Ex base station of BCS 160^{ex} BT Bluetooth hand scanner (pre-assembled)

Cable specified for connection to:	Scanner cable	Version	Length	BARTEC order no.
POLARIS supply module	RS232/RS422	smooth	1.8 m	17-21BE-M020/0000
	RS232/RS422	spiral	3.8 m	17-21BE-M030/0000

Terminal connection diagram

BCS 160^{ex} hand scanner to supply module by means of connector/adaptor.



6.7.5 Fibre-optic port (optional for 12.1")

For the fibre-optic transmission a fibre-optic converter is used inside the POLARIS and it converts the Ethernet/IP to fibre-optic signals (Ethernet/IP Ex e connection is not required).

For transmission a converter of the same type is needed for the non-hazardous area. This is included in the scope of supply.

Technical Data

Connection of the POLARIS	ST connector
External fibre-optic converter	Connection of the ST connector/RJ 45 plug
Power supply	external power pack
Data rate	100 MBit/s
Permissible ambient temperatures Storage/transport Operation	-20 °C bis +80 °C 0 °C bis +55 °C
Multi-mode Converter Range Fibre type Min. transmitting power Min. sensitivity Wave length Plug connector	MS400161 up to 2 km 62.5/125 µm or 50/125 µm 19 dBm 31 dBm 1310 m ST (MS400161)
Single-mode Converter Range Fibre type Min. transmitting power Min. sensitivity Wave length Plug connector	MS400163 up to 15 km 9/125 µm 15 dBm 31 dBm 1310 m ST (MS400163)

The POLARIS fibre-optic connection is approved for op pr. The following must be observed when installing.

DANGER

There is a risk of fatal injury in an explosive atmosphere!

- ▶ Protect the ST sockets from impact effects.
- ▶ Make sure the plug on the fibre-optic cable is connected or closed before you put the POLARIS into operation.
- ▶ The fibre optic cable must laid with protection. (e.g. robust cabling, protective tubes or cable channel)

6.8 EMC (Electromagnetic compatibility)



This is a class A unit and can cause radio interference in residential areas; if it does, the owner/managing operator may be required to implement suitable measures and pay for loss or damage.



Only shielded conductors may be used as connecting conductors. This applies both to the data line and to all other conductors too.

The data lines must be stranded in pairs.

Example 2 x 2 x 0.75 mm² LIYCY TP.

As far as possible, separate conductors should be used for power supply and data

6.8.1 Voltage supply (DC-Variants)

A regulated mains adapter with an output of at least 2 A must be used as power supply. It is not permitted to fall below or exceed the power supply of DC 24 V ± 10 % at the installation site. The voltage drop on the supply line must be observed and corrected where necessary.

The voltage drop on the supply line is calculated according to the following equation:

ΔU	Voltage drop on the supply line at power supply voltage of DC 24 V	Max. 2.4 V
ΔU	Voltage drop on the supply line with maximum permissible mains adapter overvoltage DC 24 V +10 % (26.4 V)	Max. 4.8 V (until 10 % undervoltage is achieved)
I	Electricity for a POLARIS	At least 1.5 A
A	Cable cross-section of the supply line	
κ	Specific conductance of copper	$56 \frac{m}{\Omega \cdot mm^2}$
l	Length of the supply line (consider both the outgoing and return line)	

$$R = \frac{l}{\kappa \cdot A} \quad R = \frac{\Delta U}{I} \quad \Delta U = \frac{l}{\kappa \cdot A} \cdot I$$

Examples	Cable-cross-section	Maximum line length
Supply voltage DC 24 V	0,75 mm ²	approx. 50 m
	1,5 mm ²	approx. 100 m
	2,5 mm ²	approx. 170 m

If the voltage drop cannot be balanced out or the calculation produces excessive cable cross-sections, a separate mains adapter must be installed near the installation site.

Example: pressure-tight encapsulation or ex-free area on the outside of the building.



As a result of the connection of the power supply to the POLARIS, the earth for the power supply is connected to the PE. It is essential to ensure that the earth for the power supply on the POLARIS, if this is not electrically isolated, indicates no potential difference to the PE/PA.

6.8.2 Back-up fuse

The POLARIS PROFESSIONAL is fused internally in the 10,4/12,1/12,1W model with a 2.5 A slow-blowing fuse. The fuse may be triggered in the case of voltage breaks or under-voltage.

Internal fuse		I ² value	External fuse	
Little fuse 1.6 A T	1500A@250VAC	6.83 A ² s	Siba 1.6 A F	1500A@250VAC
			Siba 2.0 A F	1500A@250VAC
			Siba 2.5 A F	1500A@250VAC
Little fuse 2.5 A T	1500A@250VAC	22.29	Eska 1.6 A M	1000A@250VAC
			Eska 2 A M	1000A@250VAC



We recommend that the POLARIS is secured with a back-up fuse to avoid triggering the internal fuse in the device. The internal fuse can only be replaced by BARTEC.

Back-up fuse DC: 2.5 A slow-blowing

The I² value is to be observed for other versions of the fuses.

6.8.3 Interference suppression

Certain basic measures must be taken to ensure freedom from interference when the POLARIS are installed:

- The interference voltages coupled into the device via power, data and signal line and the electrostatic voltage caused by contact are to be dissipated through the equipotential bonding.
- The installation point should be as far as possible away from fields of electromagnetic interference. This is especially important if there are frequency converters in the vicinity. Under certain circumstances will it be advisable to set up partitions to isolate the graphic display from interference.
- If inductive devices are fitted in the vicinity (e.g. contactor, relay or solenoid coils), especially if they are powered from the same source, protective circuits (e.g. RC elements) must be installed.
- Power supply and data cables must be laid so as to avoid interference. This can be achieved, for example, by avoiding laying such cables in close proximity to high-current carrying cables.

6.8.4 Shielding

- Only cables with braided shielding should be used (recommended cover density > 80%).
- Sheet shielding should not be used.
- Generally, connection of the shielding at both ends results in optimum damping of all interference frequencies.
- Connection of the shielding at one side only may be more advisable if a difference in potential exists and no equipotential bonding cable can be laid.

6.8.5 Connection of shielding

A low impedance connection to the circuit protective conductor is important to ensure a low current fault path. When sub-D connectors are used, the shielding should always be connected to the metal casing of the sub-D plug.

The plug casing of some controllers is not always well connected to earth. In such cases it may prove advantageous to insulate the shielding from the sub-D plug of the controller and connect it directly to the protective earth conductor by means of a cable that should be kept as short as possible (0.75 mm² ... 1.5 mm²).

6.8.6 Examples of Shielding Connections

ATTENTION

Device can be damaged by differences in potential!

► Avoid differences in potential.

Double-sided shield connection on the connecting cables:




Illustration11: Example of double-sided shield connection

Generally, connection of the shielding at both ends results in optimum damping of all interference frequencies. This method is to be recommended when there is good equipotential bonding between the individual units. In such cases it is possible to make use of the controller's voltage supply cable even if this is not electrically isolated.

Single-sided shield connection on the connecting cables:




Illustration12: Example of single-sided shield connection

Connection of the shielding at one end only is recommended when there is inadequate equipotential bonding, or none at all. In such cases an electrically isolated power supply unit must be used. Before the equipment goes into service the directions from the controller manufacturer regarding proper assembly and operation must be read carefully. They should then be applied taking full account of the recommendations we make here.

6.8.7 Ethernet cable

Als Ethernet Kabel ist ein Industrial Ethernet Kabel (4-adrig, geschirmt CAT 5) zu verwenden.

The Ethernet cable used an Industrial Ethernet cable (4-core, shielded CAT 5

As an example:

For highly flexible applications

Lapp: Type ETHERLINE® PN Cat.5 FD



For fixed application:

Eku: Type: Industrial Ethernet, 2YY(ST)CY 2x2x0,64/1,5-100GN



With 8- wire cable :
Unused wire must be grounded.

7. Commissioning

For electrical systems the relevant installation and operating specifications (e.g. Directives 2014/34/EU, BetrSichV and the applicable national ordinances, IEC 60 079-14 and the DIN VDE 0100 series) must be observed.

The operator of an electrical system in a hazardous environment must keep the operating equipment in an orderly condition, operate it correctly, monitor it and do the required maintenance and repairs.

Before commissioning the devices, check that all components and documents are there.

7.1 Final Inspection

Check the following requirements before commissioning the device:

Only open the external terminal compartment with terminals for the supply and data line(s) once it has been ensured that no potentially explosive atmosphere is present and that the power supply has been turned off.

POLARIS Panel PC

- Has the reinforcement frame between the bracket and enclosure been inserted?
- Is there no damage to seals, cable connections or glass panel?
- Are the supply and data line(s) correctly wired?
- Is the PE connection correctly earthed?
- Have the supply and data line(s) been tightened in the screw terminals?
- Are all terminal compartments closed?
- Have all cable glands been tightened and all open cable entries closed with blanking plugs?

Only start the POLARIS (if a potentially explosive atmosphere is present) once the final inspection has been carried out.

8. Operation

The device can be put into operation after the final check has been made.



The POLARIS series does not have any ON/OFF switch.

8.1 Operating System


The POLARIS series devices have the Windows 7 Ultimate or the Windows 10 IOT Enterprise LTSC operating system pre-installed. According to the licence for Windows it is not permissible to use this system as an office PC.

8.2 Commissioning Software

8.2.1 Windows 10 IoT Enterprise LRSB

The devices are delivered with active writing filter (UWF). This UWF prevents that changes in the disk drive C: can be made.


To carry out changes the UWF must be deactivated. Moreover Command Prompt (CMD) must be started as an administrator and „uwfmgr filter disable“ executed.



After a reboot the UFW is deactivated and changes in the system can be protected.

The turn on the UWF's is proceed as follows:

Start the Command Prompt (CMD) as an administrator. After the reboot of the device the command „uwfmgr filter enable“ activates the writing filter.



After the reboot the device is protected again.

Important:

- 1) To install a windows update, update a virus data bank and for changing other settings the UWF must be switched off. It can also cause problems if an applications package want to be saved on disk drive C:. In the worst case the RAM-Overlay (buffer of the changes of disk drive C:) can overrun which hinders the implementation of the applications.
- 2) Ist he UWF not activated switching off can lead to destruction of parts of the operating system up to the impossibility of another starting of the device.

8.2.2 Windows 7 Ultimate

By first introduction the operating system must be installed for the user, please follow the instructions on the screen.



The Windows 7 Ultimate operating systems do not support EWF!

8.3 On-board Bartec Recovery Solution

8.3.1 Bartec Recovery Solution

The Bartec HMI Polaris Smart devices are equipped with an On-Board-Recovery solution. The Bartec Recovery is a software package preloaded on the devices which serves the disregard of the device in the work state. In case of a mistake every device can be booted up in the Recovery mode to move afterwards the operating system into the work state.

No other software is necessary for the restoration. The Recovery service already disposes of all necessary program routines or the Recovery-Wizard to play in the operating system anew. The process can be carried out any time if necessary also on site. The duration of the process amounts approx. 25 minutes.

8.3.2 Start of the device in the Recovery mode

To change in the Recovery mode, one must press the F6 key while booting up the device. This possibility is available for approx. 10 sec. During this time the announcement **"Press F6 key to start Bartec Recovery"** appears on the screen.

ATTENTION

All data on Windows partition are definitely extinguished during the recovery of process!

► All self-provided data or use data should be protected from starting the recovery.

For the Recovery mode the hard disk contains a hidden partition to the storage of the Recover engine and the image file (effigy of the operating system). If the Recovery partition exists not any more or is damaged, the device can be restored only from an external medium or USB Flash drive.



The hidden partition is approx. 10 GB. That's why the available storage space on the hard disk is lower than the given capacity.

8.3.3 Recovery surroundings

The Recovery mode bases on a slender Windows operating system or so-called PE surroundings (Windows Preinstallation Environment). Besides, Windows starts only with a basic equipment of services and drivers.




Illustration 3: Start Windows PE.

As soon as the surroundings are completely loaded and are ready for use, the Recovery engine will check in the background whether the applications necessary for the device, tools and drivers exist. All information about internal expiries is indicated in the window CMD.




Illustration 4: CMD window with information

8.3.4 Recovery application

Should the check be concluded successfully, the Recovery application is begun (besides, the window CMD is automatically closed). Before the restoration of the device in the work state must be agreed Microsoft software Licence terms interactively.

In case of Windows 7 Embedded of operating system (Ultimate or standard) the licence terms on Windows 7 Embedded family are indicated in the window. In case of Windows 10 IoT of operating system the licence terms on Windows 10 IoT family are to be seen.




Illustration 5: Licence terms

To accept the licence terms, the option **"I accept the terms in the End User License Agreement"** must be activated or be selected. The button "Start Recovery" is released enclosed. With confirming the Recovery process is begun.



All other pictures in the instructions refer to Recovery of Windows 10 IoT Enterprise of operating system. In case of the restoration of Windows 7 Embedded Ultimate or standard of operating system the pictures look similar. Besides, all background expiries are identical, with the differences it is only about inscriptions.



The operation (navigating over window, selecting and activation of tax elements etc.) takes place via keyboard input and mouse or Track ball-Clicks as well as by Touch.

In the next window all available Recovery functions are listed. In the upper area of the window there is information about the operating system which is played in by the Recovery programme. In the middle area there are the Recovery functions. Should all conditions be given, the function is active. Otherwise the function remains inactive.




Illustration 6: Choice of functions



If the Recovery is started by an external medium, there is beside the function to move the device into the work state also other functions for backup or restoration from the available backup. It enables therefore to provide an effigy of a running and preconfigured operating system if necessary also and to play in back in the case of a mistake.

8.3.5 Restoration in the work state

With confirming the function with all matching background processes is begun immediately or without following security queries.

ATTENTION

With starting the restoration of the operating system in the work state all data on the operating system partition get lost!

- Contents and format of all other partitions on the hard disk are preserved consistently.

In the upper area of the window the inscription of the well-chosen function is indicated. In the next line – the inscription of the already running background process. Should a process be computable, the proportional issue appears in the next line how far the process is already concluded. As a rule all time-luxurious processes are computable. The progress beam in the middle of the window returns the graphic picture of the percent value. For the processes without percent issue the progress beam is indicated in the uncertain form.

ATTENTION

All background processes are automated completely, therefore no intervention is necessary. In addition, some background processes run in s. g. Single fashion or they are sensitive to the other parallel processes and to Interrupts of external periphery devices!

- To avoid the interruptions of all kind, should take place during the process no keyboard input, mouse, track ball-Clicks as well as no touching of the screen.

The Recovery begins with verifying (Calculate and comparisons of the test sum) to the available effigy file.




Illustration 7: Verify to the effigy file

After the successful check, the formatting of the operating system partition is begun.




Illustration 8: Prepare the partition

After preparing the partition all files from the effigy image stored on the Recovery partition are unpacked and transferred on the operating system partition.




Illustration 9: Transferred by system files on operating system partition

Transferring of system files is the last process with the Wiederherstellung of the operating system in the work state.

8.3.6 Finish the recovery

After the Recovery process is completely concluded, it is indicated suitable information in the window. A button in the middle of the window closes the Recovery surroundings and the device restart.




Illustration 10: Successful closure of the recovery process

After the new start of the device the operating system partition is active again and this restored operating system is begun.



The first start (so called: Ridge time boat) of the put back operating system can last some minutes. On this occasion, it is about two phases. During the first phase components of the device are recognised the hardware and are integrated into the operating system. During the second phase the final settings are put. Between the phases or within the phase the device is automatically restarted several times.

8.4 Recovery/Backup Function


The POLARIS can be restored to delivery status by means of a recovery stick.



The recovery flash drive is not included in the scope of supply.
 If necessary, contact the following contact address: support-polaris@bartec.de

8.4.1 Recovery stick image

The recovery stick image for the POLARIS Panel PC can be found on the POLARIS type label.



Addition
 e. g. Built 384

8.4.2 Backup



We expressly point out that it is the user's responsibility to make a backup of the POLARIS and all its functions!

We expressly recommend that such a backup of the POLARIS be saved on an external storage medium (USB stick [recovery stick], CD, DVD or suchlike) and/or in the company network!

8.4.3 Switching off and shutting down

Irrespective of the application, the Microsoft Windows operating system saves important data in the working memory during system operation. Before the PC or the POLARIS is switched off, this data must be saved on the hard disk.

ATTENTION

Shutting down the POLARIS in an orderly fashion prevents malfunctioning in the operating system.


- ▶ Use the Windows button to shut down or switch off the POLARIS.
- ▶ Do not switch off the POLARIS until Windows informs the user that the data has been saved (appearance of the logout script).

8.5 Network (Ethernet) Setup

Requirements

Network (Ethernet) setup: Physical connection (connection of Ethernet cable to a network).

- Go to Start ⇒ Control panel <double click>.
- Mark "Network connections" and start with <double click>.
- Select LAN connection with < double click >.



- To select the function Internet Protocol click (figure 1) on sub item "Properties"
- With a < double click > on Internet Protocol (figure 2) the function is started.




Figure 1




Figure 2

- The chart (figure 3) appears when the network and a DHCP server are available.
- Configuration example (figure 4) when no DHCP server is available.




Figure 3




Figure 4

8.6 Keyboard Settings

Keyboard customization to suit the respective application



This is not necessary with the BMS Graf pro visualisation software. The use of software from other sources must be checked in each individual case.

PS/2 Code for 49600217

Hardware definition		Keycodes for level 0 Windows	Keycodes for level 1 BMS-Graf-pro	Keycodes for level 2 WinCC flexible	Keycodes for level 3 Rockwell
button	lettering	button	button	button	button
S1	F1	F1	F1	F1	F1
S2	F2	F2	F2	F2	F2
S3	F3	F3	F3	F3	F3
S4	F4	F4	F4	F4	F4
S5	F5	F5	F5	F5	F5
S6	F6	F6	F6	F6	F6
S7	F7	F7	F7	F7	F7
S8	F8	F8	F8	F8	F8
S9	F9	F9	F9	F9	F9
S10	F10	F10	F10	F10	F10
S11	F11	F11	F11	F11	F11
S12	F12	F12	F12	F12	F12
S14	Del	Del	Del	Del	Del
S15	Info-Key	Print-Screen	Print-Screen	Print-Screen	Print-Screen
S16	Shift	Shift Left	Shift Left	Shift Left	Shift Left
S17	Alt	Alt Left	Alt Left	Alt Left	Alt Left
S18	Ctrl	Ctrl Left	Ctrl Left	Ctrl Left	Ctrl Left
S19	7 ABC	Num 7	7 /	Num 7	Num 7
S20	8 DEF	Num 8	8 (Num 8	Num 8
S21	9 GHI	Num 9	9)	Num 9	Num 9
S22	4 JKL	Num 4	4 \$	Num 4	Num 4
S23	5 MNO	Num 5	5 %	Num 5	Num 5
S24	6 PQR	Num 6	6 &	Num 6	Num 6

Hard-ware definition		Keycodes for level 0 Windows	Keycodes for level 1 BMS-Graf-pro	Keycodes for level 2 WinCC flexible	Keycodes for level 3 Rockwell
button	lettering	button	button	button	button
S25	1 STU	Num 1	1 !	Num 1	Num 1
S26	2 VWX	Num 2	2 "	Num 2	Num 2
S27	3 YZ\	Num 3	3 §	Num 3	Num 3
S28	0 :()	Num 0	0 =	Num 0	Num 0
S29	.	Num .	.	Num .	Num .
S30	- Space	Num -	-	Num -	Num -
S31	Cursor left	Cursor left	Cursor left	Cursor left	Cursor left
S32	Cursor up	Cursor up	Cursor up	Cursor up	Cursor up
S33	Cursor right	Cursor right	Cursor right	Cursor right	Cursor right
S34	ESC	ESC	ESC	ESC	ESC
S35	Cursor down	Cursor down	Cursor down	Cursor down	Cursor down
S36	Num enter	Num enter	Num enter	Num enter	Num enter
S37	Windows button	Left GUI	Left GUI	Left GUI	Left GUI
S38	Kontex-menu	App	App	App	App
S39	Home	Home	Home	Home	Home
S40	F13	F13	m	Shift F1	Left Shift F1
S41	F14	F14	n	Shift F2	Left Shift F2
S42	F15	F15	o	Shift F3	Left Shift F3
S43	F16	F16	p	Shift F4	Left Shift F4
S44	S1	Shift F1	a	Shift F9	Right Alt F1
S45	S2	Shift F2	b	Shift F10	Right Alt F2
S46	S3	Shift F3	c	Shift F11	Right Alt F3
S47	S4	Shift F4	d	Shift F12	Right Alt F4
S48	S5	Shift F5	e	Ctrl F1	Right Alt F5
S49	S6	Shift F6	f	Ctrl F2	Right Alt F6
S50	S7	Shift F7	g	Ctrl F3	Right Alt F7
S51	S8	Shift F8	h	Ctrl F4	Right Alt F8
S52	S9	Shift F9	i	Ctrl F5	Right Alt F9
S53	S10	Shift F10	j	Ctrl F6	Right Alt F10
S54	S11	Shift F11	k	Ctrl F7	Right Alt F11
S55	S12	Shift F12	l	Ctrl F8	Right Alt F12
S56	Computer-button	Scroll-Lock	Scroll-Lock	Scroll-Lock	Scroll-Lock
S60	TAB	TAB	TAB	TAB	TAB

8.6.1 Touch Screen

In the POLARIS with touch screen, the touch screen software is pre-installed already. The touch screen software is available for download under <http://www.bartec.de/automation-download/>

9. Faults and troubleshooting

Fault	Possible cause	Remedy
Nothing is shown on the display	No power supply present	Check connection of the power supply
	External back-up fuse has tripped	Check fuse
	Internal fuse has tripped	Return to the manufacturer
	Backlighting faulty	Return to the manufacturer Replace the backlighting
	Device malfunction	Return to the manufacturer
Windows doesn't start	Faults in the operating system	Install the operating system again Recovery stick
No current consumption	No power supply present	Check connection of the power supply
	External back-up fuse has tripped	Check the fuse
	Internal fuse has tripped	Return to the manufacturer
	Device malfunction	Return to the manufacturer
Display turns on and off constantly	Power supply is too low.	Check diameter and length of cable. see Chapter 6.8
Display always has stripes	Display is defective or the device doesn't boot up.	Return to the manufacturer
Dark background	The backlighting is coming to the end of its service life.	Return to the manufacturer Replace the backlighting
	Power Save activated	Press any button.
Touchscreen not working	Driver deactivated Driver not installed	Check driver installation or install a driver.
Mouse cursor and point of contact on the screen do not agree	Touchscreen calibrated incorrectly.	Calibrate touchscreen.

10. Maintenance, inspection, repair

Only trained and qualified personnel may commission and do maintenance work on the POLARIS! Trained qualified personnel are people who are familiar with the installation, assembly, commissioning and operation of the POLARIS, have been instructed about the risks and have the appropriate qualifications by virtue of the work they do.

10.1 Maintenance intervals

The mechanical status of the devices should be checked at regular intervals. The length of the maintenance intervals depends on the ambient conditions. We recommend checking at least once a year. Regular maintenance is not necessary if operated appropriately in conformance with the installation instructions and with due consideration to the ambient conditions.

DANGER

Prevent electrostatic charging in hazardous (potentially explosive) areas.

There is a risk of a fatal injury in an explosive atmosphere!

- Take devices out of hazardous areas before wiping them dry or cleaning them!

ATTENTION

There is a risk of condensation forming when installed outside. Damage to property may occur if this is not checked!

- Regularly check the POLARIS for the formation of condensation.

10.2 Inspection

Under EN/IEC 60079-17 and EN/IEC 60079-19 the owner/ managing operator of electrical installations in hazardous areas is obliged to have these installations checked by a qualified electrician to ensure that they are in a proper condition.

10.3 Maintenance and repair work

Adhere to the applicable regulations under EN/IEC 60079-17 and EN/IEC 60079-19 when servicing, doing maintenance work on and testing associated operating equipment!

Assembly/disassembly, operating and maintenance work may be done only by trained specialists. The statutory rules and other binding directives on workplace safety, accident prevention and environmental protection must be observed.

10.3.1 Instructions for Repairs

If you wish to send in a defective device for repair, please read the RMA procedure guidance first. Then fill in and sign the RMA (Return Merchandise Authorisation) form and send it to our "Retouren Center".

E-Mail: services@bartec.de

Fax: +49 7931 597-119

We cannot guarantee any contractually agreed processing times for devices that are sent in without an RMA number.

The RMA guide and the RMA form are available on our homepage for downloading.

<http://www.bartec.de>

Have you any questions? Write us an e-mail or call us.

E-Mail: services@bartec.de

Phone: +49 7931 597-444

11. Disposal

The component of the POLARIS contains metal, plastic parts and electronic components.



Our devices are intended as professional electric devices for business use only, referred to as B2B devices under the WEEE-Directive. The WEEE directive sets the framework for waste electric and electronic equipment handling procedures which are to apply throughout the EU. This means that you are not permitted to dispose of this equipment in normal household refuse. It should not be given to the collection sites set up by the public waste management authorities either but instead it should be disposed of in a separate collection in an environmentally sound manner.

Any product we supply can be returned by our customers to us when the time has come to dispose of it. We will ensure that it is disposed of in accordance with the respective applicable statutory regulations.

The sender pays the costs of the dispatch/packaging.

12. Dispatch and packaging instructions

ATTENTION

Sensitive Devices! Damage to property due to incorrect packaging!

- ▶ Take the device's maximum weight into account when selecting the packaging and mode of transport.
- ▶ Use the original packaging for transportation.

13. Accessories, spare parts

Included in the scope of the delivery:

Name	Order no.
POLARIS Panel PC with pre-installed operating system	
Driver for Mainboard and Touch	
Mounting clamps	
Reinforcement frame POLARIS 10.4" / 12.1" W	05-0205-0008
POLARIS 12.1"	05-0205-0007

Accessories/spare parts for POLARIS Panel PCs:

Name	Order no.
Visualization software BMS-Graf-Pro 7	17-28TF-0075
Ex i memory stick 4 GByte	17-71VZ-5000/0100
Mounting clamps 4 pieces	05-0091-0111
6 pieces	05-0091-0112
Keyboard in respective national language (only 12.1" W without front keys)	17-71VZ-40.0
Input devices Mouse	17-71VZ-1000
Trackball	17-71VZ-2000
Touchpad	17-71VZ-3000
Joystick with button	17-71V2-9000
Connection cable for mouse 1.8 m	05-0068-0163
3.0 m	03-0068-0204
for trackball/joystick 1.8 m	03-0068-0172
3.0 m	05-0068-0205
for touchpad 1.8 m	03-0068-0183
3.0 m	03-0068-0206
Enclosure for floor mounting with stand	
POLARIS 10.4" / 12.1" W	07-56D7-9611/9002
POLARIS 12.1"	07-56D7-9711/9002
Enclosure for wall mounting including mounting straps	05-0005-0050
POLARIS 10.4" / 12.1" W	07-56D7-9611/9001
POLARIS 12.1"	07-56D7-9711/9001
Smart Device Bluetooth	17-71VZ-....
BCS 160 ^{ex} Hand-held scanner	17-21BA-M3.S-....
External converter Converter external RS232 - RS422 Non Ex	03-9600-0258
MPI interface Converter external MPI - RS422 Non Ex	17-28TZ-0007
Original packing POLARIS 10.4" / 12.1" W	04-9035-0005
POLARIS 12.1"	04-9035-0006

14. Order numbers

POLARIS Panel PC 10,4"

Ordering information

Description	Interfaces	Code no.	Operating system	Code no.	Computer capacity	Code no.
POLARIS Panel PC 10,4"	USB Ex e/RS422 (recommended version)	37	Windows 7 Ultimate 32bit incl. Recovery (at 4 GB RAM)	S	100 GB HD	0
			Windows 10 IOT LTSB 32bit incl. Recovery (at 4 GB RAM)	K		
	Further Interface combinations on request	XX	Windows 10 IOT LTSB 64bit incl. Recovery (at 8 GB RAM)	L	128 GB SSD	2

Complete order no. 17-71V1-90 /

Please insert correct code. Technical data subject to change without notice.
 You will find the accessories with order details on the accessories pages.

POLARIS PANEL PC 12,1"

Ordering information

Description	Interfaces	Code no.	Operating system	Code no.	Computer capacity	Code no.
POLARIS Panel PC 12,1"	USB Ex e/RS422 (recommended version)	37	Windows 7 Ultimate 32bit incl. Recovery (at 4 GB RAM)	S	100 GB HD	0
			Windows 10 IOT LTSB 32bit incl. Recovery (at 4 GB RAM)	K		
	Further Interface combinations on request	XX	Windows 10 IOT LTSB 64bit incl. Recovery (at 8 GB RAM)	L	128 GB SSD	2

Complete order no. 17-71V1-80 /

Please insert correct code. Technical data subject to change without notice.
 You will find the accessories with order details on the accessories pages.

POLARIS Panel PC 12.1" W

Ordering information

Description	Code no.	Interfaces	Code no.	Operating system	Code no.	Computer capacity	Code no.
Panel PC 12.1" W with front-panel keys	0	USB Ex e/RS422 (recommended version)	37	Windows 7 Ultimate 32bit incl. Recovery (at 4 GB RAM)	S	100 GB HD	0
				Windows 10 IOT LTSB 32bit incl. Recovery (at 4 GB RAM)	K		
Panel PC 12.1" W without front-panel keys	4	Further Interface combinations on request	XX	Windows 10 IOT LTSB 64bit incl. Recovery (at 8 GB RAM)	L	128 GB SSD	2

Complete order no. 17-71V1-B /

Please insert correct code. Technical data subject to change without notice.
 You will find the accessories with order details on the accessories pages.

15. Additional information

Resistance list – polyester front foil POLARIS series

BARTEC

Page 1 of 1

The polyester front foil material used for the POLARIS series in accordance with DIN 42115, section 2, is resistant against the testing material specified as follows:

Alcohols

Ethyl alcohol
Cyclohexanone
Glycol
Glycerol
Isopropanol
Methanol

Hydrocarbons

Aliphatic hydrocarbons
General
Benzine
Benzene
Toluene
Xylene

Chlorinated hydrocarbons

Chlorofluorocarbon
Perchloroethylene
III-trichloroethane
Trichloroethylene

Ester

Ethyl acetate

Other organic solvents

Aether
Dimethyl formamide
Dioxane

Acids

Formic acid < 50 %
Acetic acid
Phosphoric acid < 30 %
Hydrochloric acid ≤ 10 %
Nitric acid ≤ 10 %

Aldehydes

Acetaldehyde
Formaldehyde

Caustic solutions

Ammonia < 2 %
Caustic soda < 2 %

Saline solutions

Alkalicarbonate
Bichromate
Prussiate of potash

Different substances

Molecular chlorine
Liquid cresolphene soaps
Oxygen
Tricresyl phosphate
Water < 100 °C
Hydrogen peroxide < 25 %

Detergents, scavengers and cleaning agents

Potassium soap
Detergent solutions (tenside)
Fabric softeners

Technical oils and fats

Cutting emulsion
Diesel oil
Varnish
Heating oil
Paraffin oil
Ricinus oil
Silicone oil
Turpentine oil and turpentine oil substitute

(Where not stated otherwise: concentration = 100%)

Polyester membranes have a limited resistance to UV light and should therefore not be exposed to direct sunlight for extended periods of time.

D_BMS791.doc • Resistance list Polyester front foil • Revision 1 / Status: July, 18th 2006 • Technical data subject to change


16. Declaration of conformity

EU Konformitätserklärung
 EU Declaration of Conformity
 Déclaration UE de conformité

BARTEC

BARTEC GmbH
 Max-Eyth-Straße 16
 97980 Bad Mergentheim
 Germany

Nº 11-71V0-7C0001_B

Wir	We	Nous
BARTEC GmbH,		
erklären in alleiniger Verantwortung, dass das Produkt	declare under our sole responsibility that the product	attestons sous notre seule responsabilité que le produit
POLARIS Serie	POLARIS serie	POLARIS série
Typ 17-71V0-****/**** Typ 17-71V1-****/**** Typ 17-71V2-****/**** Typ 17-71V3-****/**** Typ 17-71VZ-****/****		
auf das sich diese Erklärung bezieht den Anforderungen der folgenden Richtlinien (RL) entspricht	to which this declaration relates is in accordance with the provision of the following directives (D)	se référant à cette attestation correspond aux dispositions des directives (D) suivantes
ATEX-Richtlinie 2014/34/EU	ATEX-Directive 2014/34/EU	Directive-ATEX 2014/34/UE
EMV-Richtlinie 2014/30/EU	EMC-Directive 2014/30/EU	Directive-CEM 2014/30/UE
RoHS-Richtlinie 2011/65/EU	RoHS-Directive 2011/65/EU	Directive-RoHS 2011/65/UE
und mit folgenden Normen oder normativen Dokumenten übereinstimmt	and is in conformity with the following standards or other normative documents	et est conforme aux normes ou documents normatifs ci-dessous
EN 60079-0:2012+A11 :2013 EN 60079-1:2007 EN 60079-5:2007 EN 60079-7:2007 EN 60079-11:2012 EN 60079-28:2007 EN 60079-31:2014	EN 61000-6-2:2005 EN 61000-6-4:2007 +A1 :2011 EN 60529 :1991 +A1 :2000 +A2 :2013 EN61010-1 :2010	
Kennzeichnung	Marking	Marquage
Visualisierungsgerät II 2G Ex eb qb [ib op pr] IIC T4 bzw II 2G Ex db eb qb [ib op pr] IIC T4 II 2D Ex tb IIIC T120° C  Zubehör II 2G Ex ib IIC T4 II 2D Ex ib IIIC T120° C		

03-0383-0362

Seite / page / page 1 von / of / de 2

EU Konformitätserklärung
 EU Declaration of Conformity
 Déclaration UE de conformité

BARTEC

BARTEC GmbH
 Max-Eyth-Straße 16
 97980 Bad Mergentheim
 Germany

Nº 11-71V0-7C0001_B

Verfahren der EU-Baumuster- prüfung / Benannte Stelle	Procedure of EU-Type Examina- tion / Notified Body	Procédure d'examen UE de type / Organisme Notifié
IBExU 05 ATEX 1117 X 0637 IBExU, Fuchsmühlenweg 7, 09599 Freiberg, D		
CE 0044		
Bad Mergentheim, den 20.01.2017		
 i.V. Nader Halmuschi BU Leiter	 i.V. Michael Schulte Leiter GW PZ	