

**TC52, TC52-HC,  
TC52x, TC57,  
TC72, TC77, PS20,  
EC30, MC93**



**ZEBRA**

## **Best Practices Guide**

Voice

Deployment Optimization for  
Extreme Infrastructure

ZEBRA and the stylized Zebra head are trademarks of Zebra Technologies Corporation, registered in many jurisdictions worldwide. All other trademarks are the property of their respective owners. ©2021 Zebra Technologies Corporation and/or its affiliates. All rights reserved.

Information in this document is subject to change without notice. The software described in this document is furnished under a license agreement or nondisclosure agreement. The software may be used or copied only in accordance with the terms of those agreements.

For further information regarding legal and proprietary statements, please go to:

SOFTWARE: [zebra.com/linkoslegal](https://zebra.com/linkoslegal).

COPYRIGHTS: [zebra.com/copyright](https://zebra.com/copyright).

WARRANTY: [zebra.com/warranty](https://zebra.com/warranty).

END USER LICENSE AGREEMENT: [zebra.com/eula](https://zebra.com/eula).

## Terms of Use

### Proprietary Statement

This manual contains proprietary information of Zebra Technologies Corporation and its subsidiaries (“Zebra Technologies”). It is intended solely for the information and use of parties operating and maintaining the equipment described herein. Such proprietary information may not be used, reproduced, or disclosed to any other parties for any other purpose without the express, written permission of Zebra Technologies.

### Product Improvements

Continuous improvement of products is a policy of Zebra Technologies. All specifications and designs are subject to change without notice.

### Liability Disclaimer

Zebra Technologies takes steps to ensure that its published Engineering specifications and manuals are correct; however, errors do occur. Zebra Technologies reserves the right to correct any such errors and disclaims liability resulting therefrom.

### Limitation of Liability

In no event shall Zebra Technologies or anyone else involved in the creation, production, or delivery of the accompanying product (including hardware and software) be liable for any damages whatsoever (including, without limitation, consequential damages including loss of business profits, business interruption, or loss of business information) arising out of the use of, the results of use of, or inability to use such product, even if Zebra Technologies has been advised of the possibility of such damages. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

# Contents

<b>About This Guide</b> .....	<b>4</b>
Notational Conventions.....	4
Icon Conventions.....	5
Related Documents.....	5
<b>Device Settings</b> .....	<b>6</b>
Default, Supported, and Recommended for Voice Device Settings.....	6
Device Wi-Fi Quality of Service (QoS) Tagging and Mapping.....	10
<b>Network Settings and Device RF Characteristics</b> .....	<b>12</b>
Recommended Environment.....	12
Device RF Capabilities.....	13
<b>Infrastructure and Vendor Model Recommendations</b> .....	<b>14</b>
General WLAN Recommendations.....	14
WLAN Infrastructure Recommendations for Voice Support.....	15
Extreme Networks Infrastructure Recommendations for Voice Quality.....	16
Zebra Recommended WLC and AP Firmware Versions.....	16

# About This Guide

This guide provides recommendations for voice deployment using the following mobile computers and their accessories.

- TC52
- TC52-HC
- TC52x
- TC57
- TC72
- TC77
- PC20
- MC93
- EC30.

## Notational Conventions

The following conventions are used in this document:

- **Bold** text is used to highlight the following:
  - Dialog box, window, and screen names
  - Drop-down list and list box names
  - Checkbox and radio button names
  - Icons on a screen
  - Key names on a keypad
  - Button names on a screen
- Bullets (•) indicate:
  - Action items
  - List of alternatives
  - Lists of required steps that are not necessarily sequential.
- Sequential lists (for example, those that describe step-by-step procedures) appear as numbered lists.

## Icon Conventions

The documentation set is designed to give the reader more visual clues. The following graphic icons are used throughout the documentation set. These icons and their associated meanings are described below.



**NOTE:** The text here indicates information that is supplemental for the user to know and that is not required to complete a task. The text here indicates information that is important for the user to know.

## Related Documents

For the latest version of this guide and all documentation sets for the respective devices, go to: [zebra.com/support](https://zebra.com/support).

Refer to specific vendor documentation for detailed infrastructure information.

# Device Settings

This chapter includes device settings for default, supported, and voice traffic recommendations.

## Default, Supported, and Recommended for Voice Device Settings

This section includes specific recommendations for voice that are not set as the default out-of-the-box configuration. It is generally advised to examine those specific settings in alignment with the WLAN network needs and compatibilities. In some cases, changing the defaults could harm generic connectivity performance.

Besides those specific recommendations which would need careful examination, most of the device's default settings are already optimized for voice connectivity. For that reason, it is recommended to keep the defaults and let the device dynamically adjust the WLAN network dynamic feature-selection levels. Device configuration should change only if there are WLAN network (wireless LAN controller (WLC), access points (AP)) features that mandate respective changes on the device side to allow proper inter-operation.

Note the following:

- Pairwise master key identifier (PMKID) is disabled on the device by default. If your infrastructure configuration is configured for PMKID, enable PMKID and disable the opportunistic key caching (OKC) configuration.
- The Subnet Roam feature allows you to change the network IP of the WLAN interface when the network is configured for a different subnet on the same extended service set identification (ESSID).
- In execution of default fast transition (FT) (also known as FT Over-the-Air), in case that other non-FT Fast Roaming Methods might be available on the same SSID, see Fast Roam Methods in [Table 5](#) and relevant notes in [General WLAN Recommendations](#) on page 14.
- Use mobile device management (MDM) agents to change settings. Use the user interface (UI) to change parameter subsets.
- For voice applications, and for any highly-dependent client-server communication apps, it is not recommended to use the Android battery optimization feature (also known as Doze Mode) in device management tools. Battery optimization interrupts communication between dependent endpoints and servers.
- Media access control (MAC) randomization:
  - From Android Oreo onwards, Zebra devices support the MAC randomization feature, which is enabled by default. Disable or enable this via MDM or via Android privacy setting **Use Device MAC**:
    - When enabled in Android 10 versions and earlier, the randomized MAC value is used only for Wi-Fi scanning of new networks prior to association with the intended network (prior to new

connection), however, it is not used as the associated device MAC address. The associated MAC address is always the physical MAC address.

- When enabled in Android 11 onwards, the randomized MAC value is also used for association with the intended network. The randomized value is specific for each network name (SSID). It remains the same when the device roams from one AP of the connected network to different AP(s) of the same network, and/or when it has to fully re-connect to the specific network after being out of coverage.
- The MAC randomization feature does not affect voice performance and it is not necessary to disable this feature for general troubleshooting purposes. However, in some specific situations, disabling it may be helpful during the troubleshooting data collection.

The following table lists the default, supported, and recommended voice settings.

**Table 1** Default, Supported, and Recommended Voice Device Settings

Feature	Default Configuration	Supported Configuration	Recommended for Voice
Auto Time Config	Disabled	<ul style="list-style-type: none"> <li>• Enable (works only on Extreme infrastructure)</li> <li>• Disable</li> </ul>	Default
State11d	Country selection set to Auto	<ul style="list-style-type: none"> <li>• Country selection set to Auto</li> <li>• Country selection set to Manual</li> </ul>	Default

**Table 1** Default, Supported, and Recommended Voice Device Settings (Continued)

Feature	Default Configuration	Supported Configuration	Recommended for Voice
ChannelMask_2.4 GHz	All channels enabled, subject to local regulatory rules.	Any individual channel can be enabled or disabled, subject to local regulatory rules.	Device Mask matches the exact set of network side operating channels configuration.  It is recommended to configure both the device and the network to a reduced set of channels 1, 6, and 11, if WLAN SSID is enabled on 2.4 GHz.
ChannelMask_5.0 GHz	<ul style="list-style-type: none"> <li>• Up to Android Oreo Build Number 01.13.20, all non-dynamic frequency selection (DFS) channels are enabled.</li> <li>• From Android Oreo Build Number 01.18.02 onwards, Android 9 and, Android 10, all channels are enabled, including DFS.</li> </ul> <p>All the above are subject to local regulatory rules.</p>	Any individual channel can be enabled or disabled, subject to local regulatory rules.	Device Mask matches the exact set of network side operating channels configuration.  It is recommended to configure both the device and the network to a reduced set of only non-DFS channels.  For example, in North America, configure the network channels to 36, 40, 44, 48, 149, 153, 157, 161, 165.
Band Selection	Auto (both 2.4 GHz and 5 GHz bands enabled)	<ul style="list-style-type: none"> <li>• Auto (both bands enabled)</li> <li>• 2.4 GHz</li> <li>• 5 GHz</li> </ul>	5 GHz
Band Preference	Disabled	<ul style="list-style-type: none"> <li>• Enable for 5 GHz</li> <li>• Enable for 2.4 GHz</li> <li>• Disable</li> </ul>	Enable for 5 GHz, if WLAN SSID is on both bands.
Open Network Notification	Disabled	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	Default
Advanced Logging	Disabled	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	Default

**Table 1** Default, Supported, and Recommended Voice Device Settings (Continued)

Feature	Default Configuration	Supported Configuration	Recommended for Voice
User Type	Non-Restricted	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	Default
FT	Enabled	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	Default
OKC	Enabled	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	Default
PMKID	Disabled	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	Default
Power Save	NDP (Null data power save)	<ul style="list-style-type: none"> <li>• NDP</li> <li>• Power Save PS-POLL</li> <li>• Wi-Fi multimedia power save (WMM-PS)</li> </ul>	Default
11k	Enabled	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	Default
Subnet Roam	Disabled	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	Default
11w	After Android 10: Enable / Optional Before Android 10: Disable	<ul style="list-style-type: none"> <li>• Enable / Mandatory</li> <li>• Enable / Optional</li> <li>• Disable</li> </ul>	Default
Channel Width	2.4 GHz - 20 MHz 5 GHz - 20 MHz, 40 MHz and 80 MHz	Not configurable	Default
11n	Enabled	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul> <p>Note: Disabling this also disables 11ac.</p>	Default
11ac	Enabled	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	Default

## Device Wi-Fi Quality of Service (QoS) Tagging and Mapping

This section describes device QoS tagging and mapping of packets from the device to the AP (such as outgoing packets in the uplink direction).

The tagging and mapping of traffic in the downlink direction from the AP to the device is determined by the AP or controller vendor implementation or configuration, which is not in the scope of this document.

For the uplink direction, an application on the device sets Differentiated Service Code Point (DSCP) or Type of Service (ToS) values for its sourced packets, based on the application's specifications. Prior to the transmission of each packet over Wi-Fi, the DSCP or ToS values determine the device's further 802.11 Tagging ID assigned to the packet, and the mapping of the packet to 802.11 Access Category.

The 802.11 tagging and mapping columns are provided for reference and are not configurable. The IP DSCP or ToS values may or may not be configurable, depending on the app.



**NOTE:** Table 2 describes the tagging and mapping values for outgoing packets when no other dynamic protocols affect them by standard specifications. For example, if the WLAN infrastructure mandates the Call Admission Control (CAC) protocol for certain traffic types (such as voice and/or signaling), tagging and mapping obey the dynamic states of the CAC specifications. This means that there could be CAC configuration or sub-periods in which the tagging and mapping apply different values than mentioned in the table, even though the DSCP value is the same.

**Table 2** Device Wi-Fi QoS Tagging and Mapping for Outgoing Traffic

IP DSCP Class Name	IP DSCP Value	ToS Hexa	Tagging of 802.11 TID (Traffic ID) and UP (802.1d UserPriority)	Mapping to 802.11 Access Category (same as Wi-Fi WMM AC spec)
none	0	0	0	AC_BE
cs1	8	20	1	AC_BK
af11	10	28	1	AC_BK
af12	12	30	1	AC_BK
af13	14	38	1	AC_BK
cs2	16	40	2	AC_BK
af21	18	48	2	AC_BK
af22	20	50	2	AC_BK
af23	22	58	2	AC_BK
cs3	24	60	4	AC_VI
af31	26	68	4	AC_VI
af32	28	70	3	AC_BE
af33	30	78	3	AC_BE
cs4	32	80	4	AC_VI
af41	34	88	5	AC_VI
af42	36	90	4	AC_VI
af43	38	98	4	AC_VI

**Table 2** Device Wi-Fi QoS Tagging and Mapping for Outgoing Traffic (Continued)

IP DSCP Class Name	IP DSCP Value	ToS Hexa	Tagging of 802.11 TID (Traffic ID) and UP (802.1d UserPriority)	Mapping to 802.11 Access Category (same as Wi-Fi WMM AC spec)
cs5	40	A0	5	AC_VI
ef	46	B8	6	AC_VO
cs6	48	C0	6	AC_VO
cs7	56	E0	6	AC_VO

# Network Settings and Device RF Characteristics

This section describes device settings for the recommended environment and device RF characteristics.

## Recommended Environment

- Perform a Voice Grade Site Survey to ensure the requirements in [Table 3](#) are met.
- Signal to Noise Ratio (SNR), measured in dB, is the delta between the noise in dBm and the coverage RSSI in dBm. The minimum SNR value is shown in [Table 3](#). Ideally, the raw noise floor should be -90 dBm or lower.
- In floor level, Same-Channel Separation refers to two or more APs with the same channel are in RF sight of a scanning device in a given location. [Table 3](#) specifies the minimum received signal strength indicator (RSSI) delta between these APs.

**Table 3** Network Recommendations

Setting	Value
Latency	< 100 msec end-to-end
Jitter	< 100 msec
Packet Loss	< 1%
Minimum AP Coverage	-65 dBm
Minimum SNR	25 dB
Minimum Same-Channel Separation	19 dB
Radio Channel Utilization	< 50%
Coverage Overlap	20% in critical environments

**Table 3** Network Recommendations (Continued)

Setting	Value
Channel Plan	2.4 GHz: 1, 6, 11 <ul style="list-style-type: none"> <li>• No adjacent channels (overlapping)</li> <li>• Overlapping APs must be on different channels</li> </ul> 5 GHz: 36, 40, 44, 48, 149, 153, 157, 161, 165 <ul style="list-style-type: none"> <li>• If you are using DFS channels, broadcast the SSID in beacons.</li> <li>• Note: Unlicensed National Information Infrastructure-2 (U-NII-2) (DFS channels 52 to 140) and U-NII-3 (channels 149 to 165) are subject to the local regulatory rules</li> </ul>

## Device RF Capabilities

Table 4 lists the RF capabilities supported by the Zebra device. These are not configurable.

**Table 4** RF Capabilities

Setting	Value
Roam Threshold	-65dbm (cannot be modified)
Device-specific Antenna Configuration	2x2 MIMO
11n Capabilities	A-MPDU Tx/Rx, A-MSDU Rx, STBC, SGI 20/40 etc.
11ac Capabilities	Rx MCS 8-9 (256-QAM) and Rx A-MPDU of A-MSDU

# Infrastructure and Vendor Model Recommendations

This section includes recommendations for Extreme Networks infrastructure settings, including WLAN practices for enabling voice as well as more specific recommendations to manage voice traffic and maintain expected voice quality.

This section does not include a full list of WLAN configurations, but only those required verification, to accomplish successful interoperability between Zebra devices and the vendor-specific network.

The listed items may or may not be default settings of the given Extreme release version. Verification is advised.

## General WLAN Recommendations

This section lists recommendations to optimize WLAN to support voice deployment.

- For best results, use Wi-Fi Certified (voice enterprise certification from Wi-Fi Alliance) AP models.
- If SSID for voice is enabled on 2.4G band, do not enable the 11b-legacy data rates on that band unless specifically required by some restricted coverage planning or older legacy devices must be supported.
- The device chooses to roam or connect to an AP depending on the infrastructure settings in effect and the underlying dynamics of the RF ecosystem. Generally, the device scans for other available APs at certain trigger points (for example, if the connected AP is weaker than -65 dBm) and connects to a stronger AP if available.
- 802.11r: Zebra strongly recommends that the WLAN network supports 11r Fast Transition (FT) as a fast-roaming method to achieve the best WLAN and device performance and user experience.
  - 11r is recommended above other fast-roaming methods.
  - When the 11r is enabled on the network, either with pre-shared-key (PSK) security (such as FT-PSK) or with an authentication server (such as FT-802.1x), the Zebra device automatically facilitates 11r, even if other parallel non-11r methods co-exist on the same SSID network. No configuration is needed.
- Disable unused Fast Roam Methods from the SSID if possible. However, if older devices on the same SSID support a different method, that two or more methods may remain enabled if they can coexist. The device automatically prioritizes its selection per the Fast Roaming Method in [Table 5](#).
- It is a general best practice to limit the amount of SSID per AP to only those required. There is no specific recommendation on the number of SSIDs per AP as this depends on multiple RF environmental factors which are specific to each deployment. A high number of SSIDs impacts channel utilization which comprises not only users and application traffic, but also beacons traffic of all SSIDs on the channel, even those not in use.

- Call Admission Control (CAC):
  - The network's CAC feature is designed to facilitate VoIP deployments, but uses algorithmic complexities to determine whether to accept or reject new calls based on network resources in runtime.
  - Do not enable (set to mandatory) CAC on the controller without testing and validating the stability of admissions (calls) in the environment under stress and plurality conditions.
  - Be aware of devices that do not support CAC which are using the same SSID as Zebra devices support CAC. This scenario requires testing to determine how the network CAC impacts the entire eco-system.
- If WPA3 is required for the deployment, refer to the Zebra WPA3 Integrator Guide for guidance on device models that support WPA3 and configuration guidance.

## WLAN Infrastructure Recommendations for Voice Support

**Table 5** WLAN Infrastructure Recommendations for Voice Support

Setting	Value
Infra type	Controller based
Security	WPA2 or WPA3
Voice WLAN	5 GHz only
Encryption	AES Note: Do not use Wired Equivalent Privacy (WEP) or Temporal Key Integrity Protocol (TKIP).
Authentication: Server Based (Radius)	802.1X EAP-TLS/PEAP-MSCHAPv2
Authentication: Pre-Shared Key (PSK) Based	Enable both PSK and FT-PSK. Note: Device automatically selects FT-PSK. PSK is necessary to support legacy/non-11r devices on same SSID.
Operational Data Rates	2.4 GHz: <ul style="list-style-type: none"> <li>• G: 12, 18, 24, 36, 48, 54 (disable all lower rates, including 11b-legacy)</li> <li>• N: MCS 0 -15</li> </ul> 5 GHz: <ul style="list-style-type: none"> <li>• A:12, 18, 24, 36, 48, 54 (disable all lower rates)</li> <li>• AN: MCS 0 - 15</li> <li>• AC: MCS 0 - 7, 8</li> </ul> Note: Adjust rate settings according to environmental characteristics. See <a href="#">Recommended Environment</a> on page 12 to accomplish balanced AP minimum coverage.

**Table 5** WLAN Infrastructure Recommendations for Voice Support (Continued)

Setting	Value
Fast Roam Methods (See <a href="#">General WLAN Recommendations</a> on page 14)	If supported by infrastructure in priority order: <ul style="list-style-type: none"> <li>• FT (802.11R)</li> <li>• OKC or PMK Cache. Do not enable both.</li> </ul>
DTIM Interval	1
Beacon Interval	100
Channel Width	2.4 GHz: 20 MHz 5 GHz: 20 MHz
WMM	Enable
802.11k	Enable only Neighbor Report. Do not enable any 11k measurements.
802.11w	Enable as optional (not mandatory)
802.11v	Enable
AMPDU	Disable for voice.

## Extreme Networks Infrastructure Recommendations for Voice Quality

**Table 6** Extreme Networks Infrastructure Recommendations for Voice Quality

Recommendation	Required	Recommended But Not Required
Configure voice WLAN to use the 802.11a band.		✓
If using EAP authentication, ensure that fast roaming is supported (for example, FT).		✓
Use the default WLAN QoS Policy settings.	✓	
Set Bridging mode to Local.	✓	
Disable Answer Broadcast Probes.	✓	
Use the default Radio QoS Policy settings.	✓	
Set Wireless Client Power to max.	✓	

## Zebra Recommended WLC and AP Firmware Versions



**NOTE:** Model versioning recommendations in this section are based on satisfactory interop test plan results. Zebra recommends that when using other software versions not listed below, consult the WLC/AP in the Release Notes to verify that a particular version is stable and preferred by the vendor.

- RFS 6K
  - Software Version: 5.8.1.0

- RFS 7K
  - Software Version: 5.8.0.0
- NX9500
  - Software version: 5.8.3.0
- AP Models: 650, 6532, 7522, 7532, 8131

