

Description



The Remote I/O Module ANTARES 8 Digital out or 8 Digital out SCL (single channel limitation) controls up to eight intrinsically safe actuators in Equipment Category II 1G or II 1D (e.g. solenoid valves).

Its transmission channels are connected conductively to each other.

The module is intended for connection to the RCU ANTARES and to the Remote I/O system ANTARES, which were specially developed for it (see system description).

Within explosion hazardous areas the module may be set up in Zones 1 and 2.

Explosion Protection

ATEX Ex protection type II 2 (1)G Ex ib [ia IIC/IIB Ga] IIC T4 Gb
 II (1)D [Ex ia Da] IIIC

Certification PTB 11 ATEX 2014

CE marking 0044

IECEX Ex marking Ex ib [ia IIC/IIB Ga] IIC T4 Gb
[Ex ia Da] IIIC

Certification IECEX PTB 11.0054

Ambient temperature range -20 °C to +60 °C (+50 °C)

At ambient temperatures over +50 °C (max. +60 °C) the Remote I/O Module ANTARES 8DO or 8DO SCL must be operated in conjunction with distance modules art. no. 05-0078-0106.

Safety Data per transmission channel

$U_o = 27.5 \text{ V}$
 $I_o = 104 \text{ mA}$
 $P_o = 715 \text{ mW}$
 $C_i = 6 \text{ nF}$
 $L_i = \text{negligibly low}$

Ex ia IIC: $C_o = 80 \text{ nF}; L_o = 0,2 \text{ mH}$ or

$C_o = 60 \text{ nF}; L_o = 0,53 \text{ mH}$

Ex ia IIB: $C_o = 666 \text{ nF}; L_o = 0,1 \text{ mH}$ or

$C_o = 244 \text{ nF}; L_o = 11 \text{ mH}$

Standards

in conformance to Directive 94/9/EC

EN 60079-0:2009	EN 60079-11:2007
EN 61241-0:2006	EN 61241-11:2006
IEC 60079-0:2007-10	IEC 60079-11:2006
IEC 61241-0:2004	IEC 61241-11:2005

in conformance to Directive 2004/108/EC (EMC)

EN 61000-6-2:2005
EN 61000-6-4:2007
EN 55011:2009

Safety Instructions

The Remote I/O Module may be connected and assembled only by qualified personnel who are authorised and trained to assemble electric components in hazardous (potentially explosive) areas. Utilisation in areas other than those specified or the modification of the product by anyone other than the manufacturer will exempt BARTEC from liability for defects or any further liability. The generally applicable statutory rules and other binding directives relating to workplace safety, accident prevention and environmental protection must be adhered to. The Remote I/O Module may be operated only if it is clean and not damaged in any way.

Marking

Particularly important points in these instructions are marked with the following symbols:



Danger!

Non-observance leads to death or serious physical injury. The necessary safety precautions must be taken.



Caution!

Warning of damage to property and financial and penal disadvantages (e.g. loss of guarantee rights, liability claims etc.).



Attention!

Important instructions and information on preventing disadvantageous behaviour.



Note

Important instructions and information on effective, economic and environmentally compatible handling.


Technical Data



Note

More approvals and data are available at www.bartec-group.com.

Enclosure material	Polyamide
Type of protection (EN 60 529)	
- Enclosure	IP30
- 10+2 pole plug connectors	IP30, when joined together with RCU ANTARES and its accessories or other Remote I/O Modules ANTARES (see system description for configuration)
Attachment onto mounting rail	TH 35-15 mounting rail DIN EN 60715 (metal, galvanized steel)
Electric connections	plug-in tension spring clamps; 4-pole; up to 2.5 mm ² ; optional coding and numbering
Dimensions (W x H x D)	45 mm x 110 mm x 114.5 mm



Weight	approx. 390 g
Storage and transport temp.	-25 °C to +85 °C
Relative humidity	5 to 95 % non-condensing
Degree of contamination	2
Vibration (EN 60068-2-6)	2 g/7 mm; 5 Hz - 200 Hz in all 3 axes
Shock (EN 60068-2-27)	15 g, 11 ms in all 3 axes ±3 shocks/direction

Electric Data ANTARES 8DO

Number of channels	8 digital outputs Ex i (short-circuit-proof)
Galvanic isolation	between outputs and internal bus
Line break/short-circuit	adjustable for each channel with ANTARES Designer Software
No-load voltage	DC 24 V
Total current of all 8 channels	max. 160 mA (limited)
Output current	max. 40 mA per channel
Internal resistance	271 Ω
Rated output current I _N	I _N = 20 mA (U _N = 18.5 V)




Note

Currents between 40 mA and 70 mA can be supplied to each channel also. For this purpose, the short-circuit monitoring for the channel concerned must be switched off in the ANTARES Designer. However, in each individual case, this must be checked in relation to the corresponding requirement. The total current of 160mA for the module continues to apply in each case. Accordingly, if the channel current is high, the number of available outputs per module will be reduced.


Electric Data for ANTARES 8DO SCL

Number of channels	8 digital outputs Ex i (short-circuit-proof)
Galvanic isolation	between outputs and internal bus
Line break/short-circuit	adjustable for each channel with ANTARES Designer Software
No-load voltage	DC 24 V
Total current of all 8 channels	max. 160 mA
Output current	max. 20.5 mA per channel (limited)
Internal resistance	271 Ω
Rated output current I _N	I _N = 20 mA (U _N = 18.5 V)


Output level 8DO



8DO-SCL



Product Marking Remote I/O Module



B Module Housing



A Type Label and Ex Protection e.g. 8DO



C Serial Number



Accessories: Distance module, Art. no. 05-0078-0106



Danger!

A distance module (05-0078-0106) is needed on the left and right of the Remote I/O Modules ANTARES 8DO and 8DO SCL!



Note

- Exception: it is not necessary to have any distance module between the Remote I/O Modules ANTARES 8DO and 8DO SCL and a bus end module or an extension module.
- The Remote I/O Modules ANTARES 8DO and 8DO SCL may be operated without a distance module in the ambient temperature range -20°C to +50°C also.

Technical Data Distance module

The distance module does not have any electronic unit. However, the (mechanical) technical data correspond to those of the Remote I/O modules:



Dimensions (W x H x D)

22.5 mm x 110 mm x 114.5 mm

Weight

approx. ca. 70 g

Without plug-in spring clamps for the electric connection.

Installation and Commissioning



Danger!

If the modules are used in explosion hazardous areas, it is necessary to rule out processes that generate high charge levels or flowing particles in the environment.



Danger!

The ANTARES Remote I/O system must be set up in a Pollution Degree 2 or better environment under DIN EN 60664-1. Make sure there is no condensation on the remote I/O module before installing or operating it.



Caution!

Any work on explosion-protected operating equipment may be done only by authorised persons. Use original parts from BARTEC GmbH always.



Note

When working on electrical systems, the relevant installation and operating regulations must be complied with, such as e.g. Directive 1999/92/EC, Directive 94/9/EC, German Industrial Health and Safety Ordinance (BetrSichV), EN 60079-14, the DIN VDE 0100 series or other applicable national standards and ordinances. The operator of an electrical system in a hazardous environment must keep it in good condition, operate and monitor it properly and do maintenance and repairs.

The Remote I/O Module ANTARES 8DO or 8DO SCL must be placed on the mounting rail with a side spacing of approximately 10 mm from the neighbouring module as shown in Fig. 1. Position the device onto the edge of the DIN rail with upper holding keyway and snap it on the mounting rail. Align it side by side, almost seamlessly, with the neighbouring modules.

The distance module art. no. 05-0078-0106 must be mounted in the same way.

The Remote I/O Module ANTARES 8DO or 8DO SCL is connected to the mounting rail by means of a spring-mounted functional ground contact in order to dissipate ESD.




Figure 1



Figure 2

Example of installation:

When shielded conductors are used, one end of the shield must be connected with a large contact area to a shield bus (fig. 2) by means of shield terminals.

The shield bus is connected to the equipotential bonding by means of a grounding terminal 4 mm² (as in fig. 2).



It is essential to select a connection lead that satisfies the thermal and mechanical requirements of the area of application.

Rated connection capacity of the spring clamps

Permissible core cross-sections	
Clamping range single-wire	0.2 mm ² - 2.5 mm ²
Clamping range fine-stranded	0.2 mm ² - 2.5 mm ²
Clamping fine-stranded with wire-end ferrule acc. to DIN 46228-1 or DIN 46228-4	0.25 mm ² - 2.5 mm ²

Supply circuits

The separately certified ANTARES RCU supplies power to the 10+2-pole plug connector on the side of the Remote I/O Module ANTARES 8DO or 8DO SCL.

Terminals for conductors from external circuits

In the GasEx area, the EN 60079-14 "Explosive atmospheres - Part 14: Electrical installations design, selection and erection" must be observed when connecting the external conductors to the terminals.

In the DustEx area the EN 61241-14 "Electrical apparatus for use in the presence of combustible dust - Part 14: Selection and Installation" must be observed.

The conductors must be connected in accordance with the terminal connection diagram.

	Terminal block	Terminal	Description
	X4	7-	Minus terminal channel 7
		7+	Plus terminal channel 7
		8-	Minus terminal channel 8
		8+	Plus terminal channel 8
	X3	5-	Minus terminal channel 5
		5+	Plus terminal channel 5
		6-	Minus terminal channel 6
		6+	Plus terminal channel 6
	X2	3+	Plus terminal channel 3
		3-	Minus terminal channel 3
		4+	Plus terminal channel 4
		4-	Minus terminal channel 4
X1	1+	Plus terminal channel 1	
	1-	Minus terminal channel 1	
	2+	Plus terminal channel 2	
	2-	Minus terminal channel 2	

The Remote I/O Module outputs have a common ground potential

Shielding for the conductors from the external circuits



Attention!

Connection leads of 25 m or longer requires shielding! See example for the shielding plan.

Displays

LED	Colour	Meaning
PWR	GN	Supply ok; goes out if voltage is too low
ST	GN	Data exchange active
ERR1	RD	Communication error
ERR2	RD	Error in the module
ON 1-8	YE	Channel switched on
ERR 1-8	RD	Channel error break/short-circuit

Repairs



Caution!

Only authorised personnel may do any of the repairs on explosion-protected operating equipment. Use only original spare parts from BARTEC GmbH.

Replacement of the ANTARES 8DO or ANTARES 8DO SCL electronic unit

The ANTARES 8DO electronic unit, type 17-6143-1001/01**, or ANTARES 8DO SCL, type 17-6143-1010/01**, is a Remote I/O Module without a lower section to the enclosure. The electronic unit is fitted into the lower section of the enclosure (art. no. 03-0078-0121).



Note

The electronic unit can be replaced in an Ex atmosphere without shut down the voltage display (hot-swap see fig. 3-5)



Caution!

Only one electronic unit may be removed at a time when hot swapping, i.e. never pull out two electronic units at the same time.

A defective electronic unit must be replaced by one of the same type only.

The new electronic unit must be installed immediately. The lower section of the enclosure may not remain open!

- (1) Use a screwdriver to loosen the plug-in spring clamps (fig. 3).
- (2) Loosen the interlocking between the upper section and the lower section (fig. 4).
- (3) Raise the electronic unit and take it out of the lower section of the enclosure (fig. 5).



The electronic unit may be touched only on the upper section of the enclosure (see fig. 5)! (ESD danger)

- (4) Insert the new electronic unit, whereby the printed circuit boards are pushed into the guide tracks in the lower section of the enclosure until the electronic unit locks into place.
- (5) Plug the spring clamps onto the top section of the enclosure.




Figure 3

Figure 4

Figure 5

Figures 3-5 without distance modules.

Maintenance

No particular maintenance is required if the device is operated appropriately and the instructions relating to installation and ambient conditions are observed.

Accessories, Spare Parts

Distance module, coding pins, labels, etc. are available as accessories (see also BARTEC catalog).

Disposal

The components in the Remote I/O Module contain metal and plastic parts and electronic components.

The statutory requirements for electrical scrap must be observed therefore (e.g. disposal by an approved disposal company).

Order Numbers

ANTARES Remote I/O Module 8DO

➔ Type 17-6143-1001/0000

ANTARES Remote I/O Module 8DO SCL

➔ Type 17-6143-1010/0000

Distance Module

➔ Art. no. 05-0078-0106

Service Address

BARTEC GmbH
Max-Eyth-Straße 16
97980 Bad Mergentheim
Germany

Phone +49 7931 597-0
Fax +49 7931 597-119
e-Mail: info@bartec.de
Internet: www.bartec-group.com